


VATTENSTEN



Design and Quality
IKEA of Sweden

**English****IMPORTANT SAFETY INSTRUCTIONS**

For indoor use only.

Regularly check the cord, the transformer and all other parts for damage. If any part is damaged the product should not be used. Important information! Keep these instructions for future use.

English**CAUTION. FOR INDOOR USE ONLY! WARNING!**

Do not connect the chain to the supply while it is in the packing. The connecting cable can not be repaired or replaced. If the cable is damaged the entire fitting must be discarded.

Do not connect this chain electrically to another chain.

NON-REPLACEABLE BULB.

English

The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

English

ONLY USE A SAFETY TRANSFORMER WITH A SELV OUTPUT AS A SUPPLY FOR THE PRODUCT.

English

1. Wipe the surface dry where the tape will be used with a clean and dry cloth.
2. The assembly tape is permanent and is not intended to be removed. You might damage the surface under the lamp if you try to remove the tape.
3. Please keep the unused fittings for future use.

עברית

יש להשתמש אך ורק בשנאי הבטיחות בעל יציאת SELV המצורף לאריזת המוצר.

עברית

1. נגבו את אזור ההדבקה באמצעות מטלית נקייה ויבשה.
2. סרט ההדבקה קבוע ואינו מיועד להסרה. הוא עשוי לגרום נזק למשטח שמתחת למנורה במידה ותנסו להסירו.
3. שמרו את אביזרי החיבור אשר אינם בשימוש לשימוש עתידי.

עברית


הוראות בטיחות חשובות מיועד לשימו ביתי בלבד. בדקו באופן קבוע את הכבל, השנאי וכל שאר החלקים על מנת לוודא כי לא ניזוקו. במידה ונמצא כי חלקים מסוימים ניזוקו, אין להשתמש במוצר. מידע חשוב! שמרו הוראות אלה לעיון בעתיד.






עברית


שימו לב. לשימוש בתוך הבית בלבד! אזהרה! אין לחבר את שרשרת התאורה לרשת החשמל כאשר היא עדיין באריזתה. אין אפשרות לתקן או להחליף את הכבל. במידה והכבל ניזוק יש להשליך את המוצר כולו. אין לחבר שרשרת תאורה זו לשרשרת אחרת. הנורה אינה ניתנת להחלפה.

עברית

נורת המנורה אינה ניתנת להחלפה; יש להחליף את המנורה כולה כאשר הנורה מגיעה לסוף חייה.









English



The light strip can be cut at the marks. Make sure that the device is unplugged when you cut.



עברית

ניתן לחתוך את פס התאורה לפי סימנים. לפני חיתוך יש לנתק מחשמל.













5

5x






6







x3



x4

