


VIHALS



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.

יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.





על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:





- מקמו את הפריטים הכבדים ביותר במגירה התחתונה.
- הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.
- אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.













1




10077982

4x



151707

10x



151708

10x




10051660

10102154

10107001

16x




10093081

6x



10093082

6x




10005905

10099750

10106990

2x




10061178

10100254

10107020

6x




100092


1x




2




4x




4x



2x



2x



192158
192166
10100430

20x




146114

4x




109535
116560


4x




1x




2x




2x



2x




2x




150689

2x




126916

2x




150688

2x




147968

2x



158469

2x




121714

2x




16


1







2




3




4




5




6




7





8





9








10






11







13



14






English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




**Ø 8 mm
(5/16")**



1




2




70 mm
(2 3/4")

3




B




**Ø 8 mm
(5/16")**



1




2




≈ 30 mm
(≈ 1 1/4")

3




C




**Ø 3 mm
(1/8")**



1





2






≈ 30 mm
(≈ 1 1/4")



3









↕
15







⇅
15





16










17

















20




21















25





26



27

