




VIHALS



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.




יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.




על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:




מקמו את הפריטים הכבדים ביותר במגירה התחתונה.


הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.

אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.












Ø 8 mm (5/16") Ø 3 mm (1/8")		
Ø 8 mm (5/16")	Ø 8 mm (5/16")	Ø 3 mm (Ø 1/8")


--	--



367808




1



10048881


36x

2




10077982

4x




101345

8x



151705

2x




151706

2x




146113

2x



100001


1x



10061178


4x

A




10071494

6x




145718

24x



10040242

6x




119030

24x




146114




48x








1




2




3




4




5




6




7




8




9




10




11









12






14







www.IKEA.com/secure-it




English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




Ø 8 mm
(5/16")



1




2




2 3/4"
(70 mm)

3




B




Ø 8 mm
(5/16")



1




2




≈ 1 1/4"
(≈ 30 mm)

3




C




Ø 3 mm
(Ø 1/8")



1









2




≈ 1 1/4"
(≈ 30 mm)


3







16












18




19




20




21





22




23




24




25





26






27







28



3x




29






1



2



3

