

VIHALS




Design and Quality
IKEA of Sweden













English

WARNING!

Serious or fatal crushing injuries can occur from furniture tip-over. To reduce the risk of furniture tip-over:

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

Place heaviest items in the lower drawer.

Do not set TVs or other heavy objects on top of this product.

Never let children climb or hang on drawers, doors, or shelves.

Read and follow each step of the instruction carefully.

עברית

אזהרה!

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית. על מנת להפחית את הסיכון של נפילת רהיטים:

יש להקפיד ולקבע את הריהוט לקיר באמצעות אביזרי קיבוע.

על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:


הניחו את הפריטים הכבדים ביותר במגירה התחתונה.


הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.


אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.

קראו ופעלו בזהירות לפי כל שלב בהוראות.




kg



kg



kg





TV




kg


kg



kg





TV





kg



kg



kg






TV


Ø8 mm)
(5/16")
Ø3 mm)
(1/8")
Ø 8 mm
(5/16")
Ø 8 mm
(5/16")
Ø 3 mm
(Ø 1/8")



kg


109048
10087223
109049
100823
106989
10083942
3x
18
2x
2x
1x
2x
1x
367808





?
IKEA

1



36x


2



4x



8x




2x




2x



2x




1x




4x


A



6x



24x




6x




24x




48x



10090743
1x
IKEA CR
6x
10084399
6x
6x
10084399
6x


1




2









3




4




5




6




7




8




9




10




11




12





13




14











15





www.IKEA.com/secure-it





English


The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


עברית


הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.



A
Ø 8 mm
(5/16")
1
2
2 3/4"
(70 mm)
3
B
Ø 8 mm
(5/16")
1
2
≈1 ¼"
(≈ 30 mm)
3
C
Ø 3 mm
(Ø 1/8")
1
2
≈1 ¼"
(≈ 30 mm)








10083942


10083942







16




17






1x
10059644
10059619
10059620
2x
10059662
10059616
10059492
3x
10059645
10059638
10059657

18



Click!

19







20









21




22




23




24







25





26







27







28





29




1
2
3

© Inter IKEA Systems B.V. 2021