


VIHALS



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.

יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.




על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:






- מקמו את הפריטים הכבדים ביותר במגירה התחתונה.
- הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.
- אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.













10005905
10099750
10106990

2x




100092

1x




10077982

4x




151707

18x



151708

18x




10061178
10100254
10107020

6x



10051660
10102154
10107001

32x




10093081

10x




10093082

10x




150689

2x




126916

2x




150688

2x




147968

2x



158469

2x






121714

2x




22


1




2




3




4




5




6





7







9








11








13














16







↓
17











www.IKEA.com/secure-it



www.IKEA.cn/secure-it


21

English


The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית


הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.





A




**Ø 8 mm
(5/16")** 

1 


2 
70 mm
(2 3/4")


3 


B




**Ø 8 mm
(5/16")** 

1 


2 
≈ 30 mm
(≈ 1 1/4")

3 

C





**Ø 3 mm
(1/8")** 


1 


2 
≈ 30 mm
(≈ 1 1/4")

3 





⇕
22






22





24



25

