


VISTHUS



Design and Quality
IKEA of Sweden



English

WARNING!

Serious or fatal crushing injuries can occur from furniture tip-over. To reduce the risk of furniture tip-over:

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

Place heaviest items in the lower drawer.

Do not set TVs or other heavy objects on top of this product.

Never let children climb or hang on drawers, doors, or shelves.

Read and follow each step of the instruction carefully.

עברית

אזהרה!

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית. על מנת להפחית את הסיכון של נפילת רהיטים:

יש להקפיד ולקבע את הריהוט לקיר באמצעות אביזרי קיבוע.




על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:







הניחו את הפריטים הכבדים ביותר במגירה התחתונה. הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.

אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים. קראו ופעלו בהוראות לפי כל שלב בהוראות.











150689

2x




126916

2x




150688

2x




147968

2x



158469

2x



121714


2x



14

327495


1




4x




4x



4x




2x




12x

2




2x




2x

3




4x



152533


2x

4



145718

4x




100224

4x




119030

4x



130652

2x




100006

1x



107586

2x




111401



4x









146113

8x







1




2




3




4




5




6






7




8








9




10












14




15




16



17



17






18


This diagram illustrates the final step of attaching the lamp base to the table top. The lamp base, which has the IKEA logo, is shown being lowered onto the table top. Two screws are used to secure the base to the underside of the table top. A circular inset provides a magnified view of the screw heads being driven into the wood. The text '2x' indicates that two screws are used for each of the two mounting points. The part number '152516' is visible on the right side of the lamp base.

19


2x


152515








21












↕
24







25




26









28




29







30




31




32




33




34



35



36



37

