

English

Care and cleaning

Before using the mixer tap for the first time, unscrew the handspray and let the water run through the hose for a few minutes. Then screw it back on.

For daily cleaning of your mixer tap, use a soft damp cloth with a mild washing up detergent or soap, if necessary.

Never use scouring powder, steel wool or detergents that contain calcium-dissolving agents, alcohol or abrasives.

Rinse with water and dry/polish with a clean dry cloth.

To remove calcium deposits, use ordinary white vinegar diluted in water and rinse with plain water. We recommend to clean any filters on the mixer tap by rinsing with clean water once a year.



Design and Quality
IKEA of Sweden

עברית

הוראות ניקוי ותחזוקה

לפני שימוש ראשון במוצר זה, הסירו את המתז והניחו למים לזרום בצינור במשך מספר דקות. לאחר מכן, הבריגו את המתז חזרה.

לניקוי יום יומי של הברז, השתמשו במטלית רכה, טבולה במים וחומר ניקוי נוזלי עדין או סבון

אין להשתמש באבקות קרצוף, צמר פלדה, חומרים ממיס אבנית, חומצות או חומרים המכילים אלכוהול או חומרי קרצוף.

שטפו במים ונגבו לייבוש במטלית נקייה ויבשה.

על מנת להסיר אבנית מהברז, נקו בחומץ לבן רגיל, מהול במים, ושטפו במי ברז.

מומלץ לנקות את כל המסננים פעם בשנה על ידי שטיפה במים נקיים.