






ÄLSKVÄRD



Design Sarah Fager




1




2



3



4



5



Design and Quality
IKEA of Sweden

Important - Read carefully - Save for future use

IKEA of Sweden, Box 702, S-343 81 Älmhult
Complies with EN 16890:2017+A1:2021.

WARNING

- Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the cot (crib and suspended bed).
- Do not use more than one mattress in the cot (crib and suspended bed).

Suitable for cots with inner dimension 41x75 cm.
Do not use the product if any part is broken; torn or missing and use only spare parts approved by manufacturer.

A compressed product assumes its proper shape and volume within 3-4 days. The material has a distinctive smell that may linger after unpacking. Airing the product will help to eliminate the smell.

Care instruction

The cover is machine washable. It is easier to re-fit the cover again if you fold the mattress in the middle.

Advice when drying

Dry without use of a heat source (e.g. hairdryer or radiator).

Child-safe zip

The zip fastener has no tab. This is to prevent children from opening the cover and putting the contents in their mouth. Open and close the zip fastener by pushing, for example, a paper clip through the loop on the slide. Important! Make sure you always remove the paper clip afterwards.

חשוב-קראו בתשומת לב- שמרו לעיון בעתיד

IKEA of Sweden, Box 702, S-343 81 Älmhult
עומד בתקן EN 16890:2017+A1:2021.

אזהרה

- היו מודעים לסכנת אש גלויה ומקורות אחרים של חום חזק, כמו גופי חימום, גז חימום, וכדומה בקרבת מיטת התינוק.
- אין להשתמש ביותר ממזרן אחד במיטת התינוק.

מתאים למיטות תינוק במידות פנימיות 41x75 ס"מ.
אין להשתמש במוצר זה במידה ואחד החלקים שבור; קרוע או חסר ויש להשתמש רק בחלקים עודפים המאושרים על ידי היצרן.
מזרנים דחוסים חוזרים לצורתם המקורית לאחר 3-4 ימי שימוש. החומר מפיק ריח אופייני שעלול להישאר גם לאחר פתיחת האריזה. אוורור המזרן וניקוי בעזרת שואב אבק יכול לסייע בסילוק הריח.

הוראות טיפול וניקוי

הטיפול מתאים לכביסה במכונה. קל יותר להחזיר את הריפוד למקומו כאשר מקפלים את המזרן במרכזו.

עצה בזמן הייבוש

יש לייבש ללא שימוש במקורות חום (כגון מייבש לשיער או רדיאטור).

רוכסן בטיחותי לילדים

הרוכסן הפנימי אינו כולל את פיסת המתכת המיועדת לאחיזה. הדבר נעשה כדי למנוע מהילדים לפתוח את הכיסוי, לפגוע במזרן ולבלוע פיסות מילוי. פתחו וסגרו את הרוכסן בעזרת הכנסת מהדק אל הלולאה. חשוב! וודאו תמיד כי הסרתם את מהדק הנירות לאחר מכן.