

English

Care instructions

Wipe clean with a mild soapy solution. Wipe dry with a clean cloth.

Care Instruction

Fabric cover: Light stains can be removed with a textile cleaner or a damp sponge and a mild soapy solution. Vacuum clean.

Leather Cover

Cover:

- Clean with a duster or vacuum lightly using the soft brush attachment.

- Wipe dry with a clean cloth.

- Protect from direct sunlight to prevent drying-out.

Rattan

Rattan: If placed close to a radiator or other source of heat, the material can dry out and deteriorate.

For maximum quality

For maximum quality, re-tighten the screws when necessary.

עברית

הוראות טיפול

נגבו עם מטלית ומעט סבון. יבשו עם מטלית נקייה ויבשה.

הוראות טיפול

כיסוי בד: כתמים קלים ניתנים להסרה באמצעות חומר לניקוי טקסטיל או ספוגית טובולה בתמיסת סבון. נקו בשואב אבק.

ריפוד עור

ריפוד:

- נקו במטלית או שואב אבק תוך שימוש בפיית המברשת הרכה.

- נגבו לייבוש באמצעות מטלית נקייה.

- הגנו מפני אור שמש ישיר על מנת למנוע דהייט צבע והתייבשות המוצר.

רטאן

רטאן: אין להציב בקרבת רדיאטור או מקור חום אחר - למניעת התיבשות ובלאי מואץ.

להבטחת איכות מירבית

להבטחת איכות מירבית, הדקו מחדש את הברגים בעת הצורך