

BILRESA





Design and Quality
IKEA of Sweden

English

4

עברית

7



Product description

BILRESA remote control with dual button is designed to control a single product, a group of products or a scene. It's a Matter-certified smart product that works with the IKEA Home smart system or any other system that uses the Matter standard. Pair it directly with a smart product from IKEA to use it without a smart system.

Getting started

With IKEA Home smart system

To connect to an IKEA Home smart system, a hub from IKEA and the IKEA Home smart app are needed.

1. Turn the remote control on by inserting 2 x AAA HR03 batteries. It will automatically power on and go into pairing mode for 15 minutes to allow connection to an IKEA Home smart system.
2. Scan the QR Code from the yellow cover in the packaging and follow the instructions in the IKEA Home smart app to connect the remote control to the system. Each product has a unique QR code.

To put the remote control back into pairing mode, open the battery compartment and press the system button.

With a Matter-certified smart system

To connect to a smart system that uses the Matter standard, a hub and app from the same manufacturer are needed.

1. Turn the remote control on by inserting 2 x AAA HR03 batteries. It will automatically power on and go into pairing mode for 15 minutes to allow connection to a Matter-certified smart system.

2. Scan the Matter QR Code from the front cover of the Advice & Care Instructions and follow the instructions in the smart home manufacturer's app. The Matter QR Code is also printed on the remote control.

To put the remote control back into pairing mode, open the battery compartment and press the system button.

Without a smart system

Smart products from IKEA can be paired directly to each other without a smart system.

Turn the remote control on by inserting 2 x AAA HR03 batteries. Quick-press the system button 4 times and hold the remote within 5 cm of the smart product it should be paired with. Pairing mode will be open for 30 seconds.

Note, a maximum of 10 smart products from IKEA can be controlled with one remote by pairing directly. If the products intended for pairing are close together, turn off and disconnect the ones already connected while adding the next product.

Using the product

Button 1 (1) and Button 2 (2)

Single-press, multi-press or long-press to control different products or scenes.

Please note, functionality depends on the type of product and the system it is connected to. For example, button presses for an IKEA smart light bulb are: short-press to turn on/off, double-press to change colour and long-press to dim.

System button (3)

Press to put the remote control into pairing mode or to reset.

Pairing mode

The remote control needs to be in pairing mode to connect to an IKEA Home smart system, any system that uses the Matter standard or to pair directly with a smart product from IKEA.

To connect to an IKEA Home smart system or any other system that uses the Matter standard, press the system button to put the remote control into pairing mode. The pairing will be open for 15 minutes. A LED will pulse while pairing and then blink twice once connected.

To pair directly with a smart product from IKEA, quick-press the system button 4 times and hold the remote within 5 cm of the smart product it should be paired with. Pairing mode will be open for 30 seconds. A LED will blink fast while pairing and then blink twice once connected.

Factory reset

To reset the remote control, open the battery compartment and press and hold the system button for 10 seconds or until the red LED light stops blinking. It will automatically restart and be available for pairing with a smart system for 15 minutes.

Battery care

When the battery is low, a red LED light will blink twice when any button is pressed. If the remote control is connected to an IKEA Home smart system, the battery status will be also shown in IKEA Home smart app. 2 x new LADDA AAA HR03 batteries will usually power the remote for 24 months before they need to be changed.

Care instructions

To clean the product, wipe with a dry cloth.

Good to know

- If the product is connected to an IKEA Home smart system, additional features are available in the IKEA Home smart app.
- If the product is connected to another smart system that uses the Matter standard, check with the manufacturer for available features.
- When the remote control is sold together with another product in the same package, they are already paired.
- This product uses Thread technology to communicate with other smart products. A Thread border router is needed to connect to Matter systems. Many smart products or hubs, have a Thread border router built in.
- Different building materials and placement of the product can affect the wireless connectivity range.

Safety and compliance

WARNING

- Use only indoors.
- Discard the product if damaged.
- Never submerge in water or other liquids.
- The product is only suitable for mounting at heights up to 2 m.
- Children should be supervised to ensure they do not play with the product.
- Do not use batteries which are low in charge or empty.
- Always insert the batteries according to the polarity indications (+/-).
- Risk of explosion if either battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- Do not mix batteries of different capacities, types or date stamps.
- Batteries should be handed in for recycling in accordance with local environmental regulations for waste disposal.
- Operating temperature: 0° C to 40° C (32° F to 104° F).

Technical data

Model: BILRESA

Type: E2489, E2622

Input: 2 x AAA/HR03

Range: 10 m in open air.

Operating frequency: 2402 - 2480 MHz

Output power: 5 dBm (EIRP)

Recommended batteries:

LADDA AAA HR03 rechargeable batteries.

Manufacturer: IKEA of Sweden AB

Address: Box 702 SE-343 81 Älmhult SWEDEN



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.

מצב צימוד

השלט הרחוק חייב להיות במצב צימוד כדי להתחבר למערכת Matter. ניתן גם לחבר אותו ישירות למוצר חכם של איקאה.

כדי לחבר את השלט הרחוק למערכת Matter או לכל מערכת התומכת בתקן Matter, לחצו על כפתור הבקרה להפעלת מצב הצימוד. יהיה זמין למשך 15 דקות. נורית לד לבנה תהבהב במהלך הצימוד, ולאחר החיבור, היא תהבהב פעמיים. נורית לד תהבהב במהלך הצימוד, ולאחר החיבור, היא תהבהב פעמיים.

נורית לד תהבהב במהלך הצימוד, ולאחר החיבור, היא תהבהב פעמיים.

איפוס להגדרות יצרן

כדי לאפס את השלט הרחוק פתחו את תא הסוללות ולחצו לחיצה ארוכה על כפתור הבקרה למשך 10 שניות או עד שנורית הלד האדומה תפסיק להבהב. החיישן יתאפס מחדש באופן אוטומטי ויהיה זמין לצימוד עם מערכת חכמה למשך 15 דקות.

טיפול בסוללה

במידה ונדרש להחליף את הסוללה, נורית לד אדומה תהבהב פעמיים בעת לחיצה על אחד מהכפתורים. אם השלט הרחוק מחובר למערכת Matter, סטטוס הסוללה יוצג גם באפליקציית Matter. סוללות חדשות מסוג LADDA HR03 מספקות כ-24 חודשי חיי סוללה.

הוראות טיפול

לניקוי המוצר, נגבו בעזרת מטלית יבשה.

טוב לדעת

- אם המוצר מחובר למערכת Matter, יוצגו מאפיינים נוספים באפליקציית Matter.
- אם המוצר מחובר למערכת חכמה המשתמשת בתקן Matter, יש לבדוק עם היצרן לגבי הפונקציות הזמינות.
- תהליך הצימוד של השלט הרחוק והמוצר החכם הנמכרים יחד באותה אריזה, כבר בוצע עבורכם.
- מוצר זה משתמש בטכנולוגיית Thread כדי לתקשר עם מוצרים חכמים אחרים. נדרש נתב גבול כדי להתחבר למערכת Matter. מוצרים חכמים או רכזות רשת רבות כוללים נתב גבול Thread מובנה.
- חומרי בניין שונים ומיקום המוצר עשויים להשפיע על טווח הקישוריות האלחוטית.

בטיחות ותקן

אזהרה

- לשימוש ביתי בלבד.
- יש להשליך את המוצר במידה ופגום.
- אין להרטיב במים או בכל נוזל אחר.
- מוצר זה מיועד להתקנה בגובה מרבי של 2 מטרים.
- יש להשגיח על ילדים על מנת להבטיח שהם אינם משחקים עם המוצר.
- אין להשתמש בסוללות ריקות או עם עוצמת טעינה נמוכה.
- הכניסו את הסוללות לחרוץ הטעינה בהתאם לסימונים (+/-).
- החלפת הסוללה שלא בהתאם להוראות עלולה לגרום לפיצוץ. יש להשליך סוללות משומשות בהתאם להנחיות.
- אין לערבב בין סוללות בעלות יכולות, סוגים או חותמות תאריך שונות.
- יש למסור סוללות ריקות למחזור בהתאם לתקנות הרשות המקומית.
- טמפרטורות הפעלה: 40°C עד 0°C

מפרט טכני

דגם: BILRESA

סוג: E2489, E2622

מתח: 2x AAA/HR03

טווח: 10 מ' באוויר הפתוח.

תדר הפעלה: 2402-2480 MHz

הספק: 5dBm (EIRP)

סוללה מומלצת:



סוללות נטענות LADDA HR03 AAA.

יצרן: IKEA of Sweden AB

כתובת: Box 702 SE-343 81 Älmhult SWEDEN



סימן המחזור מראה שיש להשליך את המוצר בנפרד מהפסולת הביתית. יש להעביר אותו למחזור בהתאם לחוקים המקומיים. באמצעות הפרדת מוצר זה מן הפסולת הביתית, תעזרו להפחית את כמות הפסולת המועברת למשפחה או מטמנות ולמוער את ההשפעה השלילית על בריאות האנשים והסביבה. לקבלת מידע נוסף, אנא צרו קשר עם חנות איקאה הקרובה לביתכם.



כדי להחזיר את השלט הרחוק למצב צימוד, פתחו את תא הסוללות ולחצו על כפתור הבקרה.

ללא מערכת חכמה

ניתן לחבר את המוצרים החכמים של איקאה ישירות זה לזה ללא מערכת חכמה.

הכניסו 2 סוללות AAA/HR03 להדלקת השלט הרחוק. למצב צימוד, לחצו במהירות על כפתור הבקרה 4 פעמים והחזיקו את תא השלט הרחוק במרחק של 5 ס"מ מהמוצר. הצימוד יהיה זמין למשך 30 שניות.

שימו לב, ניתן לשלוט ב-10 מוצרים חכמים של IKEA לכל היותר באמצעות שלט רחוק אחד על ידי צימוד ישיר שלהם. אם המוצרים שברצונכם לצמד קרובים אחד לשני, כבו ונתקו את המוצרים שכבר מחוברים לפני הוספת מוצר חדש.

אופן שימוש במוצר

כפתור 1 (1) וכפתור 2 (2)

לחצו לחיצה אחת, מספר לחיצות או לחיצה ארוכה כדי לשלוט במוצרים או תרחישים שונים.
שימו לב שהפונקציונליות תלויה בסוג המוצר ובמערכת שאליה הוא מחובר. לדוגמה, סוגי הלחיצות עבור נורת תאורה חכמה של איקאה הם: לחיצה קצרה להפעלה/כיבוי, לחיצה כפולה לשינוי הצבע ולחיצה ארוכה כדי להתאים את הבהירות.

כפתור בקרה (3)

לחצו כדי להעביר את השלט הרחוק למצב צימוד או כדי לאפסו.

תיאור המוצר

שלט רחוק BILRESA כולל 2 לחצנים המאפשרים לכם לשלוט במוצר בודד, בקבוצת מוצרים או בתרחיש. מוצר חכם המאושר על ידי Matter ופועל עם IKEA Home smart או כל מערכת אחרת המשתמשת בתקן Matter. חברו אותו ישירות מוצר חכם ממגוון איקאה על מנת להשתמש בו ללא צורך במערכת חכמה.

הפעלה

עם מערכת הבית החכם של איקאה

כדי לחבר מוצר זה למערכת IKEA Home smart, נדרשות רכות רשת ממגוון איקאה ואפליקציית IKEA Home smart.

1. הכניסו 2 סוללות AAA/HR03 להדלקת השלט הרחוק. הוא יופעל אוטומטית וייכנס למצב צימוד למשך 15 דקות כדי להתחבר למערכת IKEA Home smart.

2. סרקו את קוד ה-QR על גבי החלק הצהוב של האריזה ועקבו אחר ההוראות באפליקציית IKEA Home smart כדי לחבר את השלט הרחוק למערכת. לכל מוצר יש קוד QR ייחודי משלו.

כדי להחזיר את השלט הרחוק למצב צימוד, פתחו את תא הסוללות ולחצו על כפתור הבקרה.

מערכת חכמה תומכת בתקן Matter

כדי להתחבר למערכת חכמה התומכת בתקן Matter, נדרש רכות רשת ואפליקצייה מאותו יצרן.

1. הכניסו 2 סוללות AAA/HR03 להדלקת השלט הרחוק. הוא יופעל אוטומטית וייכנס למצב צימוד למשך 15 דקות כדי להתחבר למערכת חכמה התומכת בתקן Matter.

2. סרקו את קוד ה-QR של Matter המופיע על חוברת הוראות הפעלה ועקבו אחר ההוראות היצרן באפליקצייה. קוד ה-QR של Matter מודפס גם על השלט הרחוק.

