

# BILRESA



Design and Quality  
IKEA of Sweden





**English**

**4**

**עברית**

**7**



## Product description

BILRESA remote control with scroll wheel is designed to control up to 3 groups of products. It's a Matter-certified smart product that works with the IKEA Home smart system or any other system that uses the Matter standard. Pair it directly with a smart product from IKEA to use it without a smart system.

## Getting started

### With IKEA Home smart system

To connect to an IKEA Home smart system, a hub from IKEA and the IKEA Home smart app are needed.

1. Turn the remote control on by inserting 2 x AAA HR03 batteries. It will automatically power on and go into pairing mode for 15 minutes to allow connection to an IKEA Home smart system.
2. Scan the QR Code from the yellow cover in the packaging and follow the instructions in the IKEA Home smart app to connect the remote control to the system. Each product has a unique QR code.

To put the remote control back into pairing mode, open the battery compartment and press the system button.

### With a Matter-certified smart system

To connect to a smart system that uses the Matter standard, a hub and app from the same manufacturer are needed.

1. Turn the remote control on by inserting 2 x AAA HR03 batteries. It will automatically power on and go into pairing mode for 15 minutes to allow connection to a Matter-certified smart system.
2. Scan the Matter QR Code from the front cover of the Advice & Care Instructions and follow the instructions in the smart home manufacturer's app. The Matter QR Code is also printed on the remote control.

To put the remote control back into pairing mode, open the battery compartment and press the system button.

## Without a smart system

Smart products from IKEA can be paired directly to each other without a smart system.

Pair one or more smart products to each of the 3 groups on the remote control. Switch between product groups by pressing beneath the LED lights. Each light controls a different group of products.

Turn the remote control on by inserting 2 x AAA HR03 batteries. Quick-press the system button 4 times and hold the remote within 5 cm of the smart product it should be paired with. Pairing mode will be open for 30 seconds and default to product group 1.

When at least one smart product is connected to group 1, group 2 will be available for pairing. Press under the LED lights until group 2 is illuminated and follow the pairing instructions above to connect products to that group. Once group 2 is connected to at least one product, group 3 can be connected.

Note, a maximum of 10 smart products from IKEA can be controlled with each group on the remote control by direct pairing. If the products intended for pairing are close together, turn off and disconnect the ones already connected while adding the next product.

## Using the product

### Wheel (1)

Scroll the wheel, single-press, multi-press and long-press to control all products in the group.

Note, wheel functions depend on the product type connected to the remote control and the system it is connected to.

### Control under the LED lights (2)

Press to switch between product groups.

### System button (3)

Press to put the remote control into pairing mode or to reset.

## Buttons and controls for smart products from IKEA

	Scroll wheel (press)	Scroll wheel (scroll)	Control under the LED light	System button
<b>Lights</b>	<ul style="list-style-type: none"> <li>Single-press: ON/OFF</li> <li>Double-press: next colour</li> <li>Triple-press: previous colour</li> </ul>	<ul style="list-style-type: none"> <li>Scroll left and right: dim the lights</li> </ul>	<ul style="list-style-type: none"> <li>Single-press: next product group</li> </ul>	<ul style="list-style-type: none"> <li>Single-press: pairing mode with a smart system;</li> <li>Quick-press 4 times: pairing directly with smart product from IKEA</li> </ul>
<b>Speakers</b>	<ul style="list-style-type: none"> <li>Single-press: PLAY/PAUSE</li> <li>Double-press: next track</li> <li>Triple-press: previous track</li> </ul>	<ul style="list-style-type: none"> <li>Scroll left and right: volume up/down</li> </ul>	<ul style="list-style-type: none"> <li>Single-press: next product group</li> </ul>	<ul style="list-style-type: none"> <li>Single-press: pairing mode with a smart system</li> </ul>
<b>Plugs</b>	<ul style="list-style-type: none"> <li>Single-press: ON/OFF</li> </ul>	N/A	<ul style="list-style-type: none"> <li>Single-press: next product group</li> </ul>	<ul style="list-style-type: none"> <li>Single-press: pairing mode with a smart system</li> <li>Quick-press 4 times: pairing directly with a smart product from IKEA</li> </ul>

### Pairing mode

The remote control needs to be in pairing mode to connect to an IKEA Home smart system, any system that uses the Matter standard or to pair directly with a smart product from IKEA.

To connect to an IKEA Home smart system or any other system that uses the Matter standard, press the system button to put the remote control into pairing mode. The pairing will be open for 15 minutes. All 3 LED will pulse while pairing and then blink twice once connected.

To pair directly with a smart product from IKEA, quick-press the system button 4 times. Select a group by pressing the control under the LED lights and hold the remote within 5 cm of the smart product it should be paired with. Pairing mode will be open for 30 seconds. The LED assigned to the selected group will blink fast while pairing and then blink twice once connected.

Please note, each group needs at least one smart product before other products can be paired to the next group.

### Factory reset

To reset the remote control, open the battery compartment and press and hold the system button for 10 seconds or until the red LED light stops blinking. It will automatically restart and be available for pairing with a smart system for 15 minutes.

### Battery care

When the battery is low, a red LED light will blink twice when any button or control is pressed. If the remote control is connected to an IKEA Home smart system, the battery status will be also shown in IKEA Home smart app. 2 x new LADDA AAA HR03 batteries will usually power the remote control for 24 months before they need to be changed.

### Care instructions

To clean the product, wipe with a dry cloth.

### Good to know

- If the product is connected to an IKEA Home smart system, additional features are available in the IKEA Home smart app.
- If the product is connected to another smart system that uses the Matter standard, check with the manufacturer for available features.
- This product uses Thread technology to communicate with other smart products. A Thread border router is needed to connect to Matter systems. Many smart products or hubs, have a Thread border router built in.
- Different building materials and placement of the product can affect the wireless connectivity range.

## Safety and compliance

### WARNING

- Use only indoors.
- Discard the product if damaged.
- Never submerge in water or other liquids.
- The product is only suitable for mounting at heights up to 2m.
- Keep batteries out of reach of children.
- Do not use batteries which are low in charge or empty.
- Always insert the batteries according to the polarity indications (+/-).
- Risk of fire or explosion if either battery is replaced by incorrect type.
- Do not mix batteries of different capacities, types or date stamps.
- Batteries should be handed in for recycling in accordance with local environmental regulations for waste disposal.
- Operating temperature: 0° C to 40° C (32° F to 104° F).

### Technical data

#### BILRESA

**Type:** E2490

**Input:** 2 x AAA/HR03

**Range:** 10 m in open air.

**Operating frequency:** 2402 - 2480 MHz

**Type:** E2704

**Input:** 2 x AAA/HR03

**Range:** 10 m in open air.

**Operating frequency:** 2402 - 2480 MHz

### Recommended batteries:

LADDA AAA HR03 rechargeable batteries.



**Manufacturer:** IKEA of Sweden AB

**Address:** Box 702 SE-343 81 Älmhult SWEDEN



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.





**ללא מערכת חכמה**

ניתן לחבר את המוצרים החכמים של איקאה ישירות זה לזה ללא מערכת חכמה.

הצמידו מוצר חכם אחד או יותר לכל אחת מ-3 הקבוצות בשלט הרחוק. החליפו בין קבוצות מוצרים על ידי לחיצה על הכפתור שמתחת לנוורות ה led. כל נורה שולטת בקבוצת מוצרים שונה.

הכניסו 2 סוללות AAA/HR03 להדלקת השלט הרחוק. למצב צימוד, לחצו במהירות על כפתור הבקרה 4 פעמים והחזיקו את השלט הרחוק במרחק של 5 ס"מ מהמוצר. הצימוד יהיה זמין למשך 30 שניות ויעבור כברירת מחדל לקבוצת מוצרים 1.

כאשר לפחות מוצר חכם אחד מחובר לקבוצה 1, קבוצה 2 תהיה זמינה לצימוד. לחצו מתחת לנוורות ה led עד שקבוצה 2 תידלק ועקבו אחר הוראות הצימוד לעיל כדי לחבר מוצרים לקבוצה זו. ברגע שקבוצה 2 מחוברת למוצר אחד לפחות, ניתן לחבר את קבוצה 3.

שימו לב, ניתן לשלוט ב-10 מוצרים חכמים של IKEA לכל היותר בכל קבוצה באמצעות שלט רחוק אחד על ידי צימוד ישיר שלהם. אם המוצרים שברצונכם לצמד קרובים אחד לשני, כבו ונתקו את המוצרים שכבר מחוברים לפני הוספת מוצר חדש.

**אופן שימוש במוצר**

**גלגלת (1)**

גללו את את הגלגלת, לחצו לחיצה אחת, מספר לחיצות לוחיצה ארוכה כדי בכל המוצרים בקבוצה. שימו לב, פונקציות הגלגלת תלויות בסוג המוצר ובמערכת שאליה הוא מחובר.

**שליטה תחת תאורת ה led (2)**

לחצו כדי לעבור בין קבוצות מוצרים.

**כפתור בקרה (3)**

לחצו כדי להעביר את השלט הרחוק למצב צימוד או כדי לאפסו.

**תיאור המוצר**

הגלגלת בשלט רחוק BILRESA תאפשר לכם לשלוט ב-1-3 מוצרים או קבוצות מוצרים בו-זמנית. מוצר חכם המאושר על ידי Matter ופועל עם IKEA Home smart או כל מערכת אחרת המשתמשת בתקן Matter. חברו אותו ישירות מוצר חכם ממוגון איקאה על מנת להשתמש בו ללא צורך במערכת חכמה.

**הפעלה**

**עם מערכת הבית החכם של איקאה**

כדי לחבר מוצר זה למערכת Matter, נדרשות רכות רשת ממוגון איקאה ואפליקציית Matter. IKEA Home smart.

1. הכניסו 2 סוללות AAA/HR03 להדלקת השלט הרחוק. הוא יופעל אוטומטית ויכנס למצב צימוד למשך 15 דקות כדי להתחבר למערכת Matter. IKEA Home smart.

2. סרקו את קוד ה-QR על גבי החלק הצהוב של האריזה ועקבו אחר ההוראות באפליקציית Matter. IKEA Home smart כדי לחבר את השלט הרחוק למערכת. לכל מוצר יש קוד QR ייחודי משלו.

כדי להחזיר את השלט הרחוק למצב צימוד, פתחו את תא הסוללות ולחצו על כפתור הבקרה.

**מערכת חכמה תומכת בתקן Matter**

כדי להתחבר למערכת חכמה התומכת בתקן Matter, נדרש רכות רשת ואפליקצייה מאותו יצרן.

1. הכניסו 2 סוללות AAA/HR03 להדלקת השלט הרחוק. הוא יופעל אוטומטית ויכנס למצב צימוד למשך 15 דקות כדי להתחבר למערכת חכמה התומכת בתקן Matter.

2. סרקו את קוד ה-QR של Matter המופיע על חוברת הוראות ההפעלה ועקבו אחר הוראות היצרן באפליקצייה. קוד ה-QR של Matter מודפס גם על השלט הרחוק.

כדי להחזיר את השלט הרחוק למצב צימוד, פתחו את תא הסוללות ולחצו על כפתור הבקרה.

