


DIRIGERA



Design and Quality
IKEA of Sweden

English

IMPORTANT SAFETY INSTRUCTIONS

Unplug the power supply unit from the power source before cleaning and when the hub is not in use.

To clean the hub and the power supply unit, wipe with a soft cloth moistened with a small amount of mild cleaning agent. Use another soft, dry cloth to wipe dry.

Never submerge the power supply unit or hub in water. Never use abrasive cleaners or chemical solvents as this can damage the products.

IMPORTANT!

- The wall socket must be located near the equipment and must be easily accessible.
- Storage temperature: -20 °C to 25 °C.
- Operating temperature: 0 °C to 40 °C.
- Do not leave the hub in direct sunlight or near any heat source, as it may overheat.
- Do not subject the hub or power supply unit to wet, damp or excessively dusty environments, as this may cause damage.
- The range between the hub and the receiver is measured in open air.
- Different building materials and placement of the units can affect the wireless connectivity range.
- Children should be supervised to ensure that they do not play with the product.
- This equipment is only suitable for mounting at heights up to 2 m.
- Recommended precautionary measures and technical data, see the back of the power supply unit.

Product servicing

Do not attempt to repair this product yourself. If you open or remove parts, you may expose yourself to dangerous voltage points or other risks.

Save these instructions for future use.

Technical data

Model: DIRIGERA hub for smart products

Type: E2315

Input: 5.0V DC

Range: 10 m in open air

Operating frequency:	Output power:
2400 - 2483.5 MHz	11.8 dBm

Indoor use only

Manufacturer: IKEA of Sweden AB

Address:

Box 702, SE-343 81 Älmhult, SWEDEN

הוראות בטיחות חשובות

נתקו את ספק הכוח מהחשמל לפני הניקוי וכשהרכות אינה בשימוש.
כדי לנקות את הרכות ואת ספק הכוח, נגבו במטלית לחה עם מעט חומר ניקוי עדין. השתמשו במטלית יבשה נוספת כדי לייבש.
לעולם אין לטבול את היחידה החשמלית או את הרכות במים.
אין להשתמש בחומרי ניקוי עוצמתיים או בממסים כימיים, שכן הם עלולים לפגוע במוצרים.

חשוב!

- על השקע להיות ממוקם ליד הצויד ועל הגישה אליו להיות קלה.
- טמפרטורת אחסון: -20°C עד 25°C .
- טמפרטורת הפעלה: 0°C עד 40°C .
- אין להשאיר את הרכות באור שמש ישיר או ליד כל מקור חום, שכן דבר זה עלול להוביל להתחממות יתר.
- אין לאחסן את הרכות או את יחידת ספק הכוח בסביבה רטובה, לחה או מאובקת מאוד, שכן סביבה כזאת עלולה לגרום לנזקים.
- הטווח שבין הרכות למקלט נמדד באוויר הפתוח.
- חומרים שונים ומיקום היחידות יכולים להשפיע על טווח הקליטה האלחוטי.
- יש להקפיד שילדים אינם משחקים עם המוצרים.
- צויד זה מתאים רק לתלייה בגובה של עד 2 מ'.
- לנהלי בטיחות מומלצים ולמידע טכני, ראו בגב יחידת ספק הכוח.

שירות מוצרים

אין לנסות לתקן את המוצר בעצמכם. במידה שתפתחו אותו או תסירו חלקים, אתם עלולים לחשוף את עצמכם למתח חשמלי מסוכן ולסיכונים אחרים.

שמרו את הוראות ההפעלה לשימוש עתידי.

מפרט טכני

דגם: רכזת DIRIGERA למוצרים חכמים

סוג: E2315

קלט: 5.0V DC

טווח: 10 מטר באוויר הפתוח

תדר פעולה:	הספק פלט:
MHz 2400-2483.5	dBm 11.8

שימוש בחלל סגור בלבד

יצרן: IKEA of Sweden AB

כתובת:

Box 702, SE-343 81, אלמהולט, שבדיה

AGREE PAR L'ANRT MAROC
Numero d'agrément:
MR 00002957 ANRT 2024
Date d'agrément: 05/07/2024