

DUKTIG



Design and Quality
IKEA of Sweden

English

3

עברית

4

English

Important - Read carefully - Save for future use

IKEA of Sweden, Box 702, S-343 81 Älmhult

Important! Read this information carefully. Retain for future reference.



Warning!

Use 4 AA/LR6 batteries only.

Do not mix old and new or different types batteries.

Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.

Batteries are to be inserted with the correct polarity (+ and -).

Exhausted batteries are to be removed from the toy.

The light diodes are operated by low-battery low electric voltage and turn off automatically after a few minutes to save energy.

Adult supervision is required when charging rechargeable batteries.

The supply terminals are not to be short-circuited.

Non-rechargeable batteries are not to be recharged.

Rechargeable batteries are to be removed from the toy before being charged.

עברית

חשוב-קראו בתשומת לב-שמרו לעיון בעתיד
IKEA of Sweden, Box 702, S-343 81 Älmhult
חשוב! קראו עלון זה בתשומת לב. שמרו לעיון בעתיד.



זהירות!

השתמשו ב-4 סוללות AA/LR6 בלבד.
אין לשלב סוללות ישנות עם חדשות או סוללות מסוגים שונים.
אין לשלב סוללות אלקליין, סוללות סטנדרטיות (פחמן-אבץ) או סוללות נטענות.
יש להכניס את הסוללות למטען על פי סימון הקוטביות (+ / -).
יש להוציא מהצעצוע סוללות ריקות.
הדיודות מופעלות על-ידי מתח חשמלי נמוך מהסוללות ונכבות אוטומטית לאחר מספר דקות כדי לחסוך אנרגיה.
טעינת הסוללות תתבצע אך ורק על ידי מבוגר או תחת השגחת מבוגר.
אין לגרום לקצר מכוון בנקודות החיבור.
אין לנסות ולטעון סוללות שאינן נטענות.
יש להוציא סוללות נטענות מהצעצוע לפני תהליך הטעינה.