

# DUKTIG



Design and Quality  
IKEA of Sweden

**English**

**3**

**עברית**

**4**

# English

## **Important - Read carefully - Save for future use**

IKEA of Sweden, Box 702, S-343 81 Älmhult

Important! Read this information carefully. Retain for future reference.



### **Warning!**

- Use 4 AA/LR6 batteries only.
- Do not mix old and new or different types batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Batteries are to be inserted with the correct polarity (+ and -).
- Exhausted batteries are to be removed from the toy.
- The light diodes are operated by low-battery low electric voltage and turn off automatically after a few minutes to save energy.
- Adult supervision is required when charging rechargeable batteries.
- The supply terminals are not to be short-circuited.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.

## חשוב-קראו בתשומת לב-שמרו לעיון בעתיד

IKEA of Sweden, Box 702, S-343 81 Älmhult

חשוב! קראו עלון זה בתשומת לב. שמרו לעיון בעתיד.



### זהירות!

- השתמשו ב-4 סוללות AA/LR6 בלבד.
- אין לשלב סוללות ישנות עם חדשות או סוללות מסוגים שונים.
- אין לשלב סוללות אלקליין, סוללות סטנדרטיות (פחמן-אבץ) או סוללות נטענות.
- יש להכניס את הסוללות למטען על פי סימון הקוטביות (+ / -).
- יש להוציא מהצעצוע סוללות ריקות.
- הדיודות מופעלות על-ידי מתח חשמלי נמוך מהסוללות ונכבות אוטומטית לאחר מספר דקות כדי לחסוך אנרגיה.
- טעינת הסוללות תתבצע אך ורק על ידי מבוגר או תחת השגחת מבוגר.
- אין לגרום לקצר מכוון בנקודות החיבור.
- אין לנסות ולטעון סוללות שאינן נטענות.
- יש להוציא סוללות נטענות מהצעצוע לפני תהליך הטעינה.