


DUKTIG



Design and Quality
IKEA of Sweden



English

Important - Read carefully - Save for future use

IKEA of Sweden, Box 702, S-343 81 Älmhult

Caution

Battery is to be inserted with the correct polarity.

Exhausted battery must be removed from the toy.

Adult supervision is required when charging a rechargeable battery.

The supply terminals are not to be short-circuited.

A non-rechargeable battery must not be recharged.

The rechargeable battery must be removed from the toy before charging.

עברית

חשוב-קראו בתשומת לב-שמרו לעיון בעתיד

IKEA of Sweden, Box 702, S-343 81 Älmhult

אזהרה

יש להקפיד להכניס את הסוללה בקוטביות הנכונה.

יש להסיר מהצעצוע סוללה ריקה.

יש צורך בהשגחת מבוגר בעת טעינת הסוללה הנטענת.

אין לקצר את חיבורי הסוללה.

אין לטעון סוללה שאינה נטענת.

יש להסיר סוללה נטענת מהצעצוע לפני הטענה.