

ENGLISH

Lantern for tealight

IMPORTANT!

Use only 1 tea light.

The distance between the lantern's top and any combustible material above it must be at least 50 cm.

IMPORTANT!

The lantern can get hot. Hang or place it on a fireproof, heat-resistant material a safe distance away from combustible materials. Never leave a lit candle unattended. Do not drop any objects, incl. matches, on the candle. Extinguish by snuffing out the flame.



Design and Quality
IKEA of Sweden

עברית

עששית לנר חימום

חשוב!

השתמשו רק בנר חימום אחד.

המרחק שבין החלק העליון של העששית וכל חומר דליק הנמצא מעליו צריך להיות 50 ס"מ לפחות.

חשוב!

העששית עלולה להתחמם. תלו או מקמו אותה על חומר חסין אש ועמיד בפני חום, במרחק בטוח מחומרים דליקים. לעולם אין להשאיר נרות דולקים ללא השגחה. יש להיזהר שלא להפיל שום חפצים, כולל גפרורים, על נרות החימום. על מנת לכבות את הנר יש לחנוק את הלהבה.