

# GRILLSKÄR



Design and Quality  
IKEA of Sweden

English

3

עברית

3

# IMPORTANT RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

**This product has been tested for domestic use.**

*This outdoor furniture requires no maintenance. However, by keeping the furniture clean and storing it properly you can enjoy it year after year.*

**Clean:** Wipe clean with a mild soapy solution. It is not recommended to clean plastic or metal furniture with a strong cleaner or an abrasive material because it may discolour or damage the surface.

**Maintenance:** Maintenance-free.

**Storing:** If possible, store your metal outdoor furniture in a dry place indoors. When stored outside, tilt the furniture and preferably use water repellent covers. Make sure air can circulate to avoid moisture.

**Repair:** The steel is protected from rust with a powder coating of plastic paint. If for some reason the coating comes off, the steel is not protected and rust may occur. To repair the damage, wipe clean and repaint to restore protection.

## Good to know

Do not use scouring-powder, steel wool, hard or sharp tools which can scratch the stainless steel surface. The damp surface can be discoloured if substances containing iron, from steel wool, nails or gravel, are allowed to remain on it. Discolouration is caused by the foreign material. Matt parts of the product will be shiny again if you sprinkle them with chalk, rub with a soft cloth, rinse with water and wipe.

# חשוב! קראו בתשומת לב ושמרו לעיון בעתיד

**מוצר זה נבדק ונמצא מתאים לשימוש ביתי.**

ריהוט גן זה אינו דורש תחזוקה. יחד עם זאת, באמצעות שמירה על ניקיון הריהוט ואחסון נכון תוכלו ליהנות ממנו שנים רבות.

**ניקיון:** נגבו באמצעות מטלית עם נוזל ניקוי עדין. לא מומלץ לנקות ריהוט מפלסטיק או מתכת עם חומר ניקוי חזק או חומר שורט כיון שהם יכולים לגרום לשינוי בצבע או לפגוע במשטח.

**תחזוקה:** ללא תחזוקה.

**אחסון:** במידת האפשר, אחסנו ריהוט החוץ ממתכת במקום יבש בתוך הבית. הטו את ריהוט החוץ במידה והא מאוחסן בסביבה חיצונית, והקפידו לכסות אותם בכיסויים אטומים למים. הקפידו לאוורר את הרהיטים כדי למנוע הצטברות לחות.

**תיקון:** הפלדה מוגנת מחלודה באמצעות ציפוי אבקה של צבע פלסטי. אם הציפוי מתקלף מסיבה כלשהי, הפלדה אינה מוגנת ועלולה להיווצר חלודה. לתיקון הנזק, נקו וצבעו מחדש.

## טוב לדעת

אין להשתמש באבקת מירוק, צמר פלדה, כלים קשיחים או חדים העלולים לשרוט את משטח פלדת האל-חלד. המשטח הלח עלול לדהות אם חומרים המכילים ברזל, כמו פלדה, צמר פלדה, מסמרים או חצץ, ישארו עליו לאורך זמן. דהייה בצבע נגרמת על ידי חומרים זרים. ניתן להשיב את הברק לחלקים בצבעי מט במוצר על ידי פיזור גיר, שפשוף עם מטלית רכה, שטיפה במים וניגוב.

