

# KLOCKREN

Design Henrik Preutz

---



Design and Quality  
IKEA of Sweden



**ENGLISH**

**4**

**עברית**

**6**

## **Cleaning**

- Before using the insert for the first time, wash and dry it carefully.
- The insert is dishwasher-safe. To prevent any marks left by limescale in the water, always wipe dry after washing. Spots and marks may be removed with a little vinegar diluted in lukewarm water.
- Do not use steel wool or anything that may scratch the surface.

## **How to use the insert**

1. Unfold the insert and put it into a pan with cold water. The water must not reach the base of the insert.
2. Boil the water and place the food in the insert.

**Good to know**

- The insert has a removable handle that can be hooked on to the fixed handle to make the insert easy to lift. While the food is boiling, remove the removable handle so it will not be hot when the insert is lifted.
- The insert can be used in most 2-5 litre pots and saucepans. However, it is unsuitable for use in pots and pans with non-stick coated interior, due to the risk of scratching the coating.
- Make sure that there always is water under the insert, because the cookware can get damaged if boiling dry.

## 6 עברית

### הוראות ניקוי

- לפני השימוש הראשון במוצר, מומלץ לנקות, לשטוף ולייבש אותו היטב.
- המוצר בטוח לניקוי במדיח כלים. כדי למנוע סימני אבנית על הכלים, מומלץ תמיד לנגב אותם לייבוש לאחר ההדחה. כתמים וסימנים ניתן להסיר באמצעות מעט חומץ מדולל במים פושרים.
- בעת ניקוי הכלי אין להשתמש בצמר פלדה או כל תכשיר ניקוי העלול לשרוט את שטח הפנים.

### הוראות שימוש בהתקן

1. פתחו את ההתקן והניחו אותו בתוך כלי עם מים קרים. המים אינם אמורים להגיע לבסיס ההתקן.
2. הרתיחו את המים והניחו את המזון בהתקן.

### טוב לדעת

- ההתקן כולל ידיות הניתנות להסרה, אותן ניתן להצמיד לידיית הקבועה

כדי להרים בקלות את ההתקן כלפי מעלה. כאשר המזון מגיע לנקודת רתיחה, מומלץ להסיר את הידיות כדי שלא יהיו חמות מדיי כאשר תרימו את המכסה.

- ההתקן מתאים לשימוש בסירים וקלחות בנפח 2-5 ליטרים. לעומת זאת, הוא אינו מתאים לסירים ומחבתות בעלי ציפוי מונע הידבקות, כיוון שקיימת סכנה לשריטת הציפוי.
- יש לוודא תמיד כי הכלי מכיל מים, כיוון שעלול להיגרם נזק לכלי ריק הנמצא על כיריים חמים.

