







KROKSJÖN



English

Instruction for use:
Assembly instructions can be found in the packaging of your wall accessories. Clean the surface with rubbing alcohol. Do not use cleaning agents containing silicone. Always follow the recommended curing time of 24 hours. In case of questions, please refer to the Assembly Instructions or contact IKEA customer support centre. For contact details, see IKEA.com.

Important:
Do not open the aluminium foil packaging with glue prior to use. Do not use adapter for drilling, only for glue solution. This product is suitable on smooth wall surfaces such as tiles, marble, glass, metal, stone and concrete. Do not use on wood, wallpaper, plasterboard, enamel varnish surfaces or plastic wall materials. Use on recommended surfaces only, otherwise the glue may cause damage when removing the wall accessory. Keep out of reach of children. After eye contact: Rinse opened eye for several minutes under running water.

After skin contact: Instantly wash with soap and water and rinse thoroughly. After swallowing: Consult a doctor in case of symptoms.

To avoid tile damage during disassembly:
Use a wrench tool or similar tool to remove the adaptor. Use scraper or similar to remove the glue residue.

Contents:
Structural adhesive (silane modified polymer, filler, additive, stabilizer and catalyst).

Use by:
See glue applicator packaging for expiration date (YYYY-MM-DD).

Storage:
Keep glue in a dry place at a temperature of +5°C to +30°C. Avoid direct sunlight. Do not store outside.

Disposal:
Dispose of the contents at a waste collection point or recycling centre in accordance with local or national regulations. Empty packaging can be disposed of with household waste according to local or national regulations.

עברית

הוראות שימוש:
הוראות ההרכבה מצורפות לארזיות אביזרי הקיר. נגבו את פני השטח באלכוהול. אין להשתמש בחומרי ניקוי המכילים סיליקון. זמן היבוש המומלץ הוא 24 שעות. במקרה של שאלות, אנא עיניו בהוראות ההרכבה או פנו למוקד שירות הלקוחות של IKEA. לפרטים נוספים, בקרו באתר IKEA.com.

חשוב:
אין לפתוח את ארזיות האלומיניום המכילה את הדבק לפני השימוש. אין להשתמש במתאם לקידוח חורים, רק למריחת דבק. מוצר זה מתאים למשטחי קיר חלקים כגון אריחים, שיש, זכוכית, מתכת, אבן ובטון. אינו מתאים לשימוש על עץ, טפטים, קיר גבס, אמיר, משטחים מצופים לכה או חומרי קיר מפלסטיק. משטחים לשימוש על גבי משטחים ייעודיים בלבד. על מנת למנוע נזק למשטח בעת הסרת אביזר הקיר, הרחקו מהשני ידם של ילדים. במקרה של מגע עם העיניים: יש לשטוף במים במשך מספר דקות. במקרה של מגע עם העור: שטפו עם הרבה מים וסבון. במקרה של בליעה: יש לפנות ליועץ רפואי.

כדי למנוע נזק לאריחים במהלך הפירוק:
השתמשו במפתח ברגים או בכלי דומה כדי להסיר את המתאם. השתמשו במגרד או בכלי דומה כדי להסיר שאריות הדבק.

מכיל:
דבק מבני (פולימר סילאן שונה, חומר מילוי, תוסף, מייצב, זרח).

לשימוש עד:
תאריך התפוגה מצוין על ארזיות גבי ארזיות הדבק (YYYY-MM-DD).

אחסון:
יש לשמור את הדבק במקום יבש בטמפרטורות +5°C עד +30°C. יש להימנע מחשיפה לאור שמש ישיר. אין לאחסן בחוץ.

סילוק אשפה:
הקפידו להשליך את תכולת המוצר בנקודת אסוף הפסולת או המחזור הקרובה אליכם - בכפוף לתקנות המקומיות והארציות. ניתן להשליך ארזיות ריקות יחד עם פסולת ביתית - בכפוף לתקנות המקומיות והארציות.