



Design and Quality  
IKEA of Sweden

**ENGLISH**

**4**

**עברית**

**5**

Before installation, store the worktops in a room with normal temperature and humidity levels.

Do not place the worktops against warm radiators, or lay them on cold floors.

Worktops that are installed above a dishwasher, washing machine or oven should be protected on the underside with FIXA diffusion barrier.

**Advice for use:**

- Do not place hot objects directly on the worktop.
- Always use a pot stand to protect the worktop surface.
- Boiling water and splatters from cooking food will not damage the worktop.
- For daily cleaning, wipe with a soft cloth dampened in water and a mild washing-up detergent or soap, if necessary.
- Do not use products that contain abrasives, ammonia or bleach. Dry with a dry, clean cloth.
- The worktop can withstand most household chemicals, including methylated spirits.
- If you spill something on the worktop, wipe clean immediately with a soft cloth dampened in water and a mild washing-up detergent or soap.
- Do not use a knife or other sharp objects directly on the worktop surface.
- This damages the worktop and makes the knife edge blunt. Always use a chopping board.

לפני ההתקנה, שמרו על משטחי העבודה ואחסנו אותם בחדר בו שוררים תנאי לחות וטמפרטורה רגילים. אין להשעין את משטחי העבודה על רדיאטורים חמים, ואין להניח את משטחי העבודה על מרצפות קרות. יש להגן על משטחי עבודה המתוקנים מעל מדיחי קלים, מכונות כביסה או תנורים באמצעות חוסם אדים FIXA המגן עליהם ומותאם להם במיוחד.

### הוראות בטיחות ושימוש:

- אין להניח דברים חמים ישירות על משטח העבודה.
- הקפידו להשתמש במעמד לסירים וכדומה כדי להגן על משטח העבודה.
- מים רותחים ונתזים ממזון מתבשל אינם אמורים לגרום למשטח העבודה כל נזק.
- לניקוי יומיומי, נגבו במטלית רכה עם מים ומעט סבון או, לפי הצורך, עם מעט חומר ניקוי עדין.
- אין להשתמש בחומרי ניקוי חזקים וקשים, באמוניה או בחומר מלבין. יש לנקות עם מטלית נקיה ויבשה.
- ניתן לנקות את משטח העבודה עם מרבית סוגי הכימיקלים, לרבות אלו המכילים כוהל.
- במידה ומשהו נשפך על משטח העבודה, נגבו אותו מיד במטלית עם מים ומעט סבון או, לפי הצורך, עם מעט חומר ניקוי עדין.
- אין להשתמש בסכין או במכשירים חדים כלשהם ישירות על המשטח, עקב הנזק הן למשטח העבודה והן לסכין עצמו, ההופך קהה יותר.
- הקפידו להשתמש בקרש חיתוך.