MYLLRA

English

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

⚠ WARNING

- **Never leave the child unattended – always keep the child within arm's reach**
- **Do not move or lift this product with the baby on it**
- **To prevent furniture tip-over and risk of serious or fatal injury changing table must be securely attached to wall.**

Important safety information!

- Be aware of the risk of open fires and other sources of strong heat, such as electric bar fires, gas fires etc. in the near vicinity of the changing unit.
- Tighten all assembly fittings properly before use. Check all fittings regularly and retighten as necessary.
- DO NOT use if any part is broken, torn or missing. Contact your local IKEA store for replacement parts. Do not substitute parts.
- It is recommended to use a changing pad with the dimensions to fit the changing table and with a thickness of maximum 2 cm. Place the changing pad in the middle of the changing surface.
- For domestic use only.
- For children up to 15 kg
- Do not attach any toys or toy bar when using the product

Care and maintenance

Wipe clean with a cloth damped in a mild cleaner. Wipe dry with a soft, clean cloth.

Design and Quality
IKEA of Sweden

© Inter IKEA Systems B.V. 2026

AA-2727458-2

עברית

חשוב! קראו בתשומת לב ושמרו לעיון בעתיד

⚠ אזהרה

- **לעולם אין להשאיר את הילד ללא פיקוח - יש לוודא כי הילד נמצא תמיד בהישג ידכם.**
- **אין להזיז או להרים את המוצר בעוד התינוק בתוכו.**
- **על מנת למנוע את נפילת שידת החתלה, יש לקבע אותה לקיר באמצעות אבזר הקיבוע.**

המידע בטיחות חשוב!

- שימו לב לסכנות הנובעות מאש גלויה ומקורות חום אחרים כגון תנורים חשמליים ותנורי גז בסביבה הקרובה לשולחן ההחתלה.
- יש לחזק את כל הברגים והחיבורים לפני השימוש. יש לוודא הידוק כל הברגים והחיבורים בקביעות ולחזק במידת הצורך.
- אין להשתמש במוצר זה באם חסר חלק כלשהו או אם חלק כלשהו ניזוק קרוע או שבור. צרו קשר עם שירות הלקוחות בחנות IKEA הקרובה למקום מגוריכם לחלקי חילוף. אין להשתמש בחלקים שאינם מקוריים.
- מומלץ להשתמש ברפידת החתלה בעובי שאינו עולה על 2 ס"מ ובמידות המתאימות לגודל שולחן ההחתלה. יש להניח את רפידת ההחתלה במרכז שולחן ההחתלה.
- לשימוש בתוך הבית בלבד.
- מיועד לילדים במשקל של עד 15 ק"ג.
- אין לחבר צעצועים או קשת צעצועים למוצר בעת השימוש במוצר.

טיפול ואחזקה לאורך זמן

נגבו במטלית לחה הטבולה בחומר ניקוי עדין. יש לייבש בעזרת מטלית יבשה ורכה.