

# ENGLISH

## Care and Cleaning

Let water run through the mixer tap before using it for the first time. Screw off the aerator and water through it for about 5 minutes. Then screw it back on again.

For daily cleaning of your mixer tap, use a soft cloth dampened with water and a mild washing up detergent or soap, if necessary. Never use scouring powder, steel wool or a detergent that is calcium-dissolving, sour or contains alcohol or an abrasive. Rinse with water and dry/polish with a clean dry cloth.

To remove calcium deposits, use ordinary white vinegar diluted in water and rinse with plain water.

We recommend removing the aerator on the mixer tap and cleaning it now and then. If the aerator has a build-up of calcium, wash it with vinegar solution.

We recommend to clean any filters on the tap by rinsing with clean water once a year.



Design and Quality  
IKEA of Sweden

## עברית

### מידע שימושי והוראות

הניחו למים מהברז לזרום לפני השימוש הראשון. הסירו את וסת הספיקה והניחו למים לזרום 5 דקות בערך. לאחר מכן הבריגו את וסת הספיקה בחזרה.

לניקוי יום יומי של הברז, השתמשו במטלית רכה, ספוגה במים וחומר ניקוי נוזלי עדין או סבון. אין להשתמש באבקות קרצוף, צמר פלדה, חומרים ממיסי אבנית, חומצות או חומרים המכילים אלכוהול או חומרי קרצוף. שטפו במים ונגבו במטלית נקויה ויבשה.

על מנת להסיר אבנית מהברז, נקו בחומץ לבן רגיל מהול במים ושטפו במי ברז.

אנו ממליצים להסיר את וסת הספיקה מהברז ולנקות אותו מדי פעם. במידה והצטברה אבנית בפילטר, מומלץ לנקות אותו בתמיסת חומץ.

אנו ממליצים לנקות מסננים ע"י שטיפה במי ברז פעם בשנה.