



Design and Quality  
IKEA of Sweden

**English**

**3**

**עברית**

**4**

English

# IMPORTANT RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

**This product has been tested for domestic use.**

*This outdoor furniture requires no maintenance.*

*However, by keeping the furniture clean and storing it properly you can enjoy it year after year.*

**Clean:** Wipe clean with a mild soapy solution. It is not recommended to clean plastic or metal furniture with a strong cleaner or an abrasive material because it may discolour or damage the surface.

**Maintenance:** Maintenance-free.

**Storing:** If possible, store your plastic outdoor furniture in a dry and cool place indoors. When stored outside, tilt the furniture and preferably use water-repellent covers. Make sure air can circulate to avoid moisture. In freezing temperatures, plastic can weaken and is not recommended for use.

# חשיבותו! בתשומת לב ושמרו לעינן בעתיד

**מוצר זה נבדק ונמצא מתאים לשימוש ביתי.**

ריהוט גן זה אינו דורש תחזוקה. יחד עם זאת, באמצעות שימירה על ניקיון הריהוט ואחסון נכון תוכלו להננות ממנו שנים רבות.

**ניקיון:** נגבו באמצעות מטלית עם נוזל ניקוי עדין. לא מומלץ לנוקות ריהוט פלסטיק או מתקת עם חומר ניקוי חזק או חומר שורט כיוון שהם יכולים לגרום לשינוי בצבע או לפגוע במשטח.

**תחזוקה:** ללא תחזוקה.

**אחסון:** במידת האפשר, יש לאחסן את ריהוט הגן פלסטיק במקום קרייר ויבש בתוך הבית. אם מאחסנים בחוץ, יש להטות את הרהיטים ולהשתמש בכיסויים דוחים מים. יש לוודא כי הרהיטים מאוררים כדי למנוע הצברות לחות. בטמפרטורות קפואות, פלסטיק עשוי להיחלש ואני מומלץ לשימוש.