

SOLSTOL



Design and Quality
IKEA of Sweden

English

4

עברית

6

English



Read instructions carefully and keep for future reference.

SOLSTOL lock allows the user to easily lock cabinets and drawers with the included pre-paired key tags. SOLSTOL lock can be mounted on most IKEA cabinets and drawers.

Product features

- The lock comes with two pre-paired key tags.
- Other Type-A key tags compliant with ISO/IEC 14443 can be paired with the lock.
- Single Type-A key tag compliant with ISO/IEC 14443 can be paired with any number of SOLSTOL locks.
- The lock emits a warning signal when the batteries run low.
- Safety feature opens the lock before the batteries die.

IMPORTANT!

- The lock fits cabinet doors and drawer fronts which are less than 30 mm thick.
- The lock is not suitable for metal or glass cabinets and drawers.

Instructions for use

- Install the lock and lock-plate according to the assembly instructions for your product. Ensure that nothing is blocking the lock's pin after installation. If the pin is obstructed when locking/unlocking, the lock will emit a signal that indicates this.
- Insert batteries and check that both the pre-paired key tags work with the lock before first use. **NOTE!** The package does not include batteries.
- To lock/unlock, hold the paired key tag close to the reader. If an unpaired key tag is used, the lock will emit a signal that indicates this.
- If batteries run low, the lock will emit a low battery warning signal every 4 hours and every time it is locked/unlocked. Replace the batteries promptly. If the batteries are not replaced before they die, the lock will open automatically and remain open.
- To reset the lock, press and hold the button for 10 seconds. **Note!** All paired key tags will have their current pairing erased.

TIP!

We recommend that you put one of the paired key tags in a safe place as a spare key. **Note!** there are no spare key tags available at IKEA.

Instructions for using other Type-A key tags compliant with ISO/IEC 14443

- Other Type-A key tags compliant with ISO/IEC 14443 (for ex. library card, membership card and public transport card) can be used as a key tag for SOLSTOL lock. You can pair up to 10 key tags at the time with one lock.
- To add a new key tag, press and hold the button for 2 seconds until a sound signal can be heard. Hold the new key tag close to the reader. The lock will emit a confirmation sound when the new key tag is paired.
- To remove the pairing of key tags, reset the lock.

WARNING

- Discard the product if damaged.
- Use only indoors.
- Never submerge in water or other liquids.
- Children should be supervised to ensure they do not play with the product.
- Do not use batteries which are low in charge or empty.
- Always insert the batteries into the charging slots according to the polarity indications (+/-).
- Risk of explosion if either battery is replaced by an incorrect type.
- Do not mix batteries of different capacities, types or date stamps.
- Batteries should be handed in for recycling in accordance with local environmental regulations for waste disposal.

Care instructions

To clean the product, wipe with a dry cloth.

Good to know

- The lock works for approx. 24 months without changing the batteries. This applies when using 2 x LADDA AA HR6 2450 mAh batteries and when the lock is opened/closed 3 times per day.
- Operating temperature: 0 °C to 40 °C (32 °F to 104 °F).

Recommended battery types

LADDA AA HR6 rechargeable batteries.

Technical data:

Model: SOLSTOL

Type: E2135

Input: 2 x AA/HR6

Operating frequency: 13.56 MHz

Output power: -26.08 dBμA at 10m

Manufacturer: IKEA of Sweden AB

Address: Box 702, SE-343 81 Älmhult, SWEDEN



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.

עברית



קראו את ההוראות בעיון ושמרו לשימוש עתידי.

מנעול SOLSTOL מאפשר למשתמש לנעול בקלות ארונות ומגירות עם כרטיסי המפתח המצורפים מראש. ניתן להרכבה על רוב הארונות והמגירות ממגוון איקאה.

מאפייני המוצר

- המנעול מגיע עם 2 כרטיסי מפתח מחוברים מראש.
- ניתן לחבר למנעול כרטיסי מפתח אחרים מסוג A העומדים בתקן ISO/IEC 14443.
- ניתן לחבר כרטיס מפתח בודד מסוג A העומד בתקן ISO/IEC 14443 עם מספר מנעול SOLSTOL.
- המנעול מאותת כאשר יש צורך בהחלפת הסוללות.
- פונקציית בטיחות הפותחת את המנעול לפני שהסוללות מתרוקנות במלואן.

מידע חשוב!

- המנעול מתאים לדלתות של ארון ולחזיתות מגירה בעובי של פחות מ-30 מ"מ.
- המנעול אינו מתאים לארונות/מגירות ממתכת או זכוכית.

הוראות שימוש

- התקינו את המנעול ואת לוחית המנעול בהתאם להוראות ההרכבה. ודאו כי אין דבר החוסם את סיכת המנעול לאחר ההתקנה. במידה והסיכה חסומה, המנעול יאותת בעת הפתיחה/סגירה.
- הכניסו סוללות ובדקו ש-2 כרטיסי המפתח שחוברו מראש פועלים יחד עם המנעול לפני השימוש הראשון. שימו לב! האריזה אינה כוללת סוללות.
- לפתיחת/סגירת המנעול החזיקו את כרטיס המפתח המחובר קרוב לאזור הקריאה. במידה ונעשה שימוש בכרטיס המפתח ללא חיבורו למנעול, יישמע צליל אזהרה.
- במידה והסוללות נחלשות, יידלק סימן אזהרה במנעול כל 4 שעות ובכל פעם שהוא ננעל/נפתח. יש להחליף את הסוללה באופן מיידי. אם הסוללות לא יוחלפו לפני שהתרוקנו במלואן, המנעול יפתח אוטומטית.
- לאיפוס המנעול, לחצו והחזיקו את הכפתור במשך 10 שניות. שימו לב! הגדרות החיבור של כל כרטיסי המפתח יימחקו.

טיפ!

מומלץ לשמור את אחד מכרטיסי המפתח המחוברים במקום בטוח כמפתח חליפי. שימו לב! אין להשיג כרטיסים חליפיים באיקאה.

הוראות שימוש בכרטיסי מפתח אחרים מסוג A העומדים בתקן ISO/IEC 14443

- כרטיסי מפתח אחרים מסוג A העומדים בתקן ISO/IEC 14443 (כגון) למשל כרטיס ספרייה, כרטיס חבר וכרטיס תחבורה ציבורית יכולים לשמש כמפתח למנעול SOLSTOL. ניתן לחבר עד 10 כרטיסי מפתח למנעול אחד בו-זמנית.
- כדי להגדיר כרטיס מפתח חדש, לחצו והחזיקו את הכפתור במשך 2 שניות עד לשמיעת איתות. החזיקו את כרטיס המפתח החדש קרוב לאזור הקריאה. המנעול יאותת לאחר שתהליך החיבור בוצע בהצלחה.
- אפסו את המנעול להסרת חיבור כרטיסי המפתח.

אזהרה

- יש להשליך את המוצר במידה ופגום.
- לשימוש ביתי בלבד.
- אין להרטיב במים או בכל נוזל אחר.
- יש להשגיח על ילדים על מנת להבטיח שהם אינם משחקים עם המוצר.
- אין להשתמש בסוללות ריקות או עם עוצמת טעינה נמוכה.
- הכניסו את הסוללות לחריצי הטעינה בהתאם לסימונים (+/-).
- החלפת הסוללה בסוג שאינו מתאים עלולה לגרום לפיצוץ.
- אין לערבב סוללות מסוגים שונים, קיבולות שונות או חותמות תאריך שונות.
- יש למסור סוללות ריקות למחזור בהתאם לתקנות הרשות המקומית.

הוראות טיפול

לניקוי המוצר, נגבו בעזרת מטלית יבשה.

טוב לדעת

- המנעול יכול לעבוד כ-24 חודשים ללא צורך בהחלפת סוללות. בשימוש עם 2 סוללות LADDA מסוג AA HR6 2450 mAh ובתנאי שהמנעול נפתח/נסגר עד 3 פעמים ביום.
- טמפרטורות הפעלה: 40°C עד 0°C

סוללה מומלצת:

סוללות נטענות LADDA AA HR6.

מפרט טכני:

דגם: SOLSTOL

סוג: E2135

מתח כניסה: 2 AA/HR6 x

תדירות הפעלה: 13.56 MHz

מתח יציאה: -26.08 dBμA ב-10 מטר

יצרן: IKEA of Sweden AB

כתובת: Box 702, SE-343 81 Älmhult, SWEDEN

סימן המחזור מראה שיש להשליך את המוצר בנפרד מהפסולת הביתית. יש להעביר אותו למחזור בהתאם לחוקים המקומיים. באמצעות הפרדת מוצר זה מן הפסולת הביתית, תעזרו להפחית את כמות הפסולת המועברת למשרפות או מטמנות ולמזער את ההשפעה השלילית על בריאות האנשים והסביבה. לקבלת מידע נוסף, אנא צרו קשר עם חנות איקאה הקרובה לביתכם.



AGREE PAR L'ANRT MAROC
Numero d'agrément:
MR 00000469 ANRT 2024
Date d'agrément: 02/02/2024