

SUNNERSTA



Design and Quality
IKEA of Sweden

English

3

עברית

4

English

Cleaning sinks in stainless steel

- A sink in stainless steel does not absorb taste or smell and will keep fresh for many years if cleaned at regular intervals. Therefore, wipe the sink clean with a damp cloth or sponge and washing-up detergent, if necessary, after use. Rinse the bowl with water and then wipe the sink with a dry cloth to avoid lime stains from dried-up water. You should also wipe up washing-up detergent or cleaner to avoid stains. Do not leave chlorous liquids in the bowl or on the sink for several hours, as chlorine can damage the sink and make the stainless steel surface matt.
- Stains which can't be removed by normal wiping can be rubbed off with a soft brush or a nylon sponge and liquid cleaner. Do not use cleaners containing abrasives. Rinse with water and wipe with a dry cloth.
- Always wipe and rub the sink lengthwise when cleaning.

Good to know

- Do not use scouring-powder, steel wool, hard or sharp tools which can scratch the stainless steel surface. The damp surface can be discoloured if substances containing iron, from steel wool, nails or gravel, are allowed to remain on it. Discolouration is caused by the foreign material.
- Matt parts of the sink will be shiny again if you sprinkle them with chalk, rub with a soft cloth, rinse with water and wipe the surface dry.

עברית

הוראות ניקוי לכיור פלדת אל-חלד

- כיור מפלדת אל-חלד אינו סופג ריחות ויישאר כחדש למשך שנים רבות אם תנקו אותו באופן קבוע. לכן, נקו את הכיור במטלית לחה או ספוג וחומר ניקוי נוזלי לאחר כל שימוש. שטפו את הכיור במים ונגבו לייבוש במטלית יבשה כדי למנוע כתמי אבנית. כמו כן, יש להסיר לחלוטין את חומרי הניקוי כדי להימנע מהיווצרות כתמים. אין להשאיר תמיסות כלור בכיור למשך זמן ממושך, כיוון שהכלור עלול להזיק לכיור ולעמעם את ברק פלדת האל-חלד.
- כתמים קשים במיוחד יש לנקות באמצעות מברשת רכה או ספוג ניילון וחומר ניקוי נוזלי. אין להשתמש בחומרי ניקוי הכוללים חומרי קרצוף. שטפו במים ונגבו לייבוש במטלית רכה.
- בעת הניקוי יש לנגב ולקרצף את הכיור לאורכו.

טוב לדעת

- אין להשתמש באבקת קרצוף, צמר פלדה, כלי מטבח קשים או חדים היכולים לשרוט את שטח הפנים של הכיור. אין להשאיר צמר פלדה, מסמרים או אבנים בכיור כיוון שאלו מכילים ברזל ועלולים להכתים את הכיור.
- במידה וחלקים מסוימים אבדו את הברק, יש לפזר עליהם מעט גיר, לשפשף במטלית רכה, לשטוף במים ולנגב לייבוש.