



Design and Quality
IKEA of Sweden

English

CLEAN AND CARE

Limescale deposits

- Clean with a soft cloth dampened with water and a mild washing-up detergent or soap. Never use scouring powder, steel wool or a detergent that is calcium-dissolving, sour or contains alcohol or an abrasive. Rinse with water and dry/polish with a clean dry cloth.
- To remove larger limescale deposits – use diluted, ordinary white vinegar and rinse with water.

Cleaning nozzles of head and hand showers

- Rub away limescale deposits with your hands.

Leaking from joints between various components

- Possible cause: The washers are not fixed in place correctly or are damaged.
- Check that the washers are fixed in place correctly and according to the assembly instructions.
- Replace damaged washers.

עברית

ניקיון וטיפול

אבנית

- נקו באמצעות מטלית רכה ולחה עם מעט סבון. לעולם אין להשתמש באבקת ניקוי, צמר פלדה או חומר ניקוי ממס סידן, חומץ או מכיל אלכוהול או ניקוי העלול לגרום לשפשופים. שטפו במים ויבשו עם מטלית יבשה ונקייה.
- על מנת להסיר כמויות רבות של אבנית - השתמשו בחומץ לבן מדולל רגיל ושטפו במים.

ניקוי זרבוביות הראש והידיים במקלחת

- נגבו שאריות אבנית באמצעות הידיים שלכם.

ניזילה מהחיבורים בין כמה חלקים

- גורמים אפשריים: חלקי השטיפה אינם מותקנים במקומם כראוי או פגומים.
- בדקו שחלקי השטיפה מותקנים כראוי במקומם ובהתאם להוראות ההרכבה.
- החליפו חלקי שטיפה פגומים.