

GRILLPLATS





Design and Quality
IKEA of Sweden

日本語

4

English

6



製品の説明

GRILLPLATS/グリルプラッツ プラグは接続されていない製品をワイヤレスでコントロールできます。このスマート製品はMatter規格に準拠しています。IKEA Home smartシステムまたはMatter規格を採用するほかのスマートシステムで操作できます。イケアのリモコンまたは人感センサーと直接ペアリングして、スマートシステムを使わずに使用できます。

ご使用になる前に

IKEA Home smartシステムに接続する

IKEA Home smartシステムに接続するには、イケアのハブとIKEA Home smartアプリが必要です。

1. プラグをコンセントに差し込みます。自動的に15分間ペアリングモードになり、IKEA Home smartシステムに接続できるようになります。
2. パッケージ内の黄色のカバーにある2次元コードをスキャンし、IKEA Home smartアプリにアクセスし、プラグに接続します。アプリの指示に従って、「使い方&お手入れ方法」の表紙または接続する製品上にあるMatterロゴの付いた2次元コードをスキャンします。

プラグがしばらく使用されていない場合は、ON/OFFボタンを押して、ペアリングモードに戻します。

Matter規格に準拠するスマートシステムを使用する場合
Matter規格を採用するスマートシステムに接続するには、同じメーカーのハブとアプリが必要です。

1. プラグをコンセントに差し込みます。自動的に15分間ペアリングモードになり、Matter規格のスマートシステムに接続できるようになります。
2. スマートホームメーカーのアプリの指示に従って、「使い方&お手入れ方法」の表紙または製品上にあるMatterロゴの付いたQRコードをスキャンします。

プラグがしばらく使用されていない場合は、ON/OFFボタンを押して、ペアリングモードに戻します。

スマートシステムを使わない場合

プラグをコンセントに差し込み、ペアリングするイケアのリモコンまたは人感センサーのペアリング手順に従ってください。プラグの電源が入ると、ペアリングモードになり、いつでもスマート製品と接続できるようになります。

直接ペアリングすることで、1台のリモコンまたは人感センサーに最大10個までのイケアのプラグを接続できます。ペアリングするプラグ同士が近くにある場合に新しく製品を追加する際は、既に接続されている製品をOFFにして接続を切ってください。

製品の使用

ON/OFFボタン (1)

押しと、プラグのON/OFFを切り替えたり、ペアリングモードにしたり、リセットしたりできます。

ペアリングモード

IKEA Home smartシステムもしくはMatter規格に準拠したシステムに接続する、またはイケアのリモコンもしくは人感センサーと直接ペアリングするには、プラグの電源を入れ、ペアリングモードにする必要があります。

IKEA Home smartシステムまたはMatter規格に準拠したシステムに接続するには、ON/OFFボタンを押してプラグをペアリングモードにします。15分間ペアリングモードになります。スマートホームメーカーのアプリの指示に従ってください。接続すると、LEDライトが2回点滅します。

リモコンまたは人感センサーと直接ペアリングするには、ペアリングするスマート製品の説明書に従ってください。接続すると、LEDライトが2回点滅します。なお、プラグは電源を入れるとペアリングモードのままになり、いつでもスマート製品と直接ペアリング接続できるようになります。

工場出荷時の設定にリセットする

プラグをリセットするには、ON/OFFボタンを10秒間、または赤いLEDの点滅が止まるまで長押しします。これにより、古いデータがクリアされ、既存の接続が削除されます。プラグは自動的に再起動し、15分間スマートシステムとのペアリングが可能になります。プラグがどのスマートシステムにも接続されていない場合は、ペアリングモードのままになり、いつでもスマート製品との直接ペアリング接続が可能になります。

お手入れ方法

お手入れの際は乾いた布で拭いてください。

お役立ち情報

- 製品同士を相互に直接ペアリングすることも、IKEA Home smartシステムやMatter規格に準拠したシステムに接続することもできます。一度に使用できる接続方法は1つだけです。
- 二次元コードは製品ごとに異なります。
- この「使い方&お手入れ方法」の説明書は、必要なときにご覧いただけるよう大切に保管してください。これには、製品をIKEA Home smartシステムやMatter規格に準拠したシステムに接続するために必要な、Matterロゴ付きの二次元コードが記載されています。
- 周囲の温度が最大動作温度を超えると、プラグは自動的にOFFになります。温度が安全なレベルに戻ると、プラグは再び使用できるようになります。
- 本製品をIKEA Home smartシステムに接続している場合は、IKEA Home smartアプリで追加機能を利用できます。
- 本製品をMatter規格に準拠したスマートシステムに接続している場合、利用可能な機能については製造元に確認してください。
- 本製品はThreadテクノロジーを使用して他のスマート製品と通信します。Matterシステムに接続するには、Threadボーダールーターが必要です。多くのスマート製品やハブには、Threadボーダールーターが内蔵されています。

- Matter規格に準拠した製品をスマートシステムに接続するには、2.4GHz帯で動作するルーターの使用を推奨します。
- ワイヤレス（無線）接続範囲は、建物の材質や製品の設置場所によっても変わります。

安全性&コンプライアンス

警告

- 屋内の乾燥した場所でのみ使用してください。
- 破損した場合には、すぐに使用を中止し、製品を廃棄してください。
- 水などの液体がかからないよう注意してください。
- 連結して使用しないでください。
- 使用中にカバー等で覆わないでください。
- 本製品に負荷がかかり過ぎないようにしてください。
- 電源を切るには、コンセントから電源プラグを抜いてください。
- 直射日光の当たる場所や熱源のそばに本製品を放置しないでください。
- 必ず大人が使用してください。これはおもちゃではありません。お子さまには使用させないでください。
- 動作温度：0° C - 40° C (32° F - 104° F)。

テクニカルデータ

型式：GRILLPLATS

タイプ：E2491-JP

入力：100 - 110 V~、50/60Hz

最大出力ワット数：1000 W / 10 A

抵抗負荷/最大300Wモーター負荷

到達距離：障害物のない空間で10m



動作周波数：2402 - 2480MHz

電波出力：10dBm (EIRP)

製造業者：IKEA of Sweden AB

住所：Box 702 SE-343 81 Älmhult SWEDEN

English



Product description

GRILLPLATS plug enables wireless control of any non-connected household products. It's a Matter-certified smart product that works with the IKEA Home smart system or any other system that uses the Matter standard. Pair it directly with a remote control or motion sensor from IKEA to use it without a smart system.

Getting started

With IKEA Home smart system

To connect to an IKEA Home smart system, a hub from IKEA and the IKEA Home smart app are needed.

1. Connect the plug to a power outlet. It will automatically go into pairing mode for 15 minutes to allow connection to the IKEA Home smart system.
2. Scan the QR Code from the yellow cover in the packaging to access the IKEA Home smart app and connect the plug. Following instructions in the app, scan the QR Code with the Matter logo from the front of the Advice & Care Instructions or printed on the product.

If the plug has been idle for a while, press the ON/OFF button to put it back into pairing mode.

With a Matter-certified smart system

To connect to a smart system that uses the Matter standard, a hub and app from the same manufacturer are needed.

1. Connect the plug to a power outlet. It will automatically go into pairing mode for 15 minutes to allow connection to a Matter-certified smart system.
2. Follow the instructions in the smart home manufacturer's app and scan the QR Code with the Matter logo from the front of the Advice & Care Instructions or printed on the product.

If the plug has been idle for a while, press the ON/OFF button to put it back into pairing mode.

Without a smart system

Connect the plug to a power outlet and follow the pairing instructions of the remote control or motion sensor from IKEA that it should be paired with. When the plug is powered on, it will stay in pairing mode to allow connection with smart products at any time.

Note, a maximum of 10 plugs from IKEA can be connected with one remote control or motion sensor by direct pairing. If the plugs intended for pairing are close together, turn off and disconnect the ones already connected while adding the next product.

Using the product

ON/OFF button (1)

Press to turn the plug on or off, to put it into pairing mode or to reset.

Pairing mode

The plug needs to be powered on and in pairing mode to connect to an IKEA Home smart system, any system that uses the Matter standard or to pair directly with a remote control or motion sensor from IKEA.

To connect to an IKEA Home smart system or any other system that uses the Matter standard, press the ON/OFF button to put the plug into pairing mode. The pairing will be open for 15 minutes. Follow pairing instructions in the smart home manufacturer's app. The LED light will blink twice once connected.

To pair directly with a remote control or motion sensor, follow the instructions of the smart product it should be paired with. The LED light will blink twice once connected. Note, the plug will stay in pairing mode once it is powered on to allow direct pairing connection with smart products at any time.

Factory reset

To reset the plug, press and hold the ON/OFF button for 10 seconds or until the red LED light stops blinking. This will clear old data and remove any existing connections. The plug will automatically restart and be available for pairing with a smart system for 15 minutes. If it is not connected to any smart system, it will stay in pairing mode to allow direct pairing connection with smart products at any time.

CARE INSTRUCTIONS

To clean the product, wipe with a dry cloth.

Good to know

- The products can be either paired directly to each other or connected to the IKEA Home smart system or any other system that uses the Matter standard. Only one connection method can be used at a time.
- QR Codes are unique to each product.
- Keep the Advice & Care Instructions for future reference. It contains the QR Codes with the Matter logo that are required to connect the products to IKEA Home smart system or any other system that uses Matter standard.
- The plug will turn off if the ambient temperature rises above its maximum operational limit. When the temperature returns to a safe level, the plug will be ready for use again.
- If the product is connected to an IKEA Home smart system, additional features are available in the IKEA Home smart app.
- If the product is connected to another smart system that uses the Matter standard, check with the manufacturer for available features.

- This product uses Thread technology to communicate with other smart products. A Thread border router is needed to connect to Matter systems. Many smart products or hubs, have a Thread border router built in.
- To connect Matter-certified products to a smart system, routers operating on the 2.4 GHz band are recommended.
- Different building materials and placement of the product can affect the wireless connectivity range.

Safety and compliance

WARNING

- Use only indoors in dry areas.
- Discard the product if damaged.
- Never submerge in water or other liquids.
- Do not connect after each other in a sequence.
- Do not cover the product when in use.
- Do not overload the product.
- To disconnect the power, unplug from power source.
- Do not leave the product in direct sunlight or near a heat source as it may overheat.
- For adult use only. This is not a toy and is not intended for use by children.
- Operating temperature: 0° C to 40° C (32° F to 104° F).

Technical data

Model: GRILLPLATS

Type: E2491-JP

Input: 100 - 110 V~, 50/60Hz

Max output power: 1000 W / 10 A

Resistive load/ Max 300W motor load

Range: 10 m in open air.

Operating frequency: 2402 - 2480 MHz

Output power: 10 dBm (EIRP)

Manufacturer: IKEA of Sweden AB

Address: Box 702 SE-343 81 Älmhult SWEDEN

