

HORNFELS

1.8m

5' 11"

125V ~ 60Hz 15A



AA-2538246-3

Made in China

© Inter IKEA Systems B.V. 2024

IKEA of Sweden AB
SE-343 81 Älmhult



Design and Quality
IKEA of Sweden

1R15-IDG DM

日本語	4
-----	---

English	6
---------	---

日本語



この説明書をよくお読みになり、必要なときにご覧いただけるよう大切に保管してください。

重要！

- ・ 連結して使用しないでください。
- ・ 使用中にカバー等で覆わないでください。
- ・ 電源を切るには、電源プラグを抜いてください。
- ・ 室内の乾燥した場所でのみ使用してください。

警告

- ・ 破損した場合には、すぐに使用を中止し、製品を廃棄してください。
- ・ 温度負荷が大きくなり、ほどけている場合にのみ動作します。
- ・ 本製品に負荷がかかり過ぎないようにしてください。
- ・ 充電器に水などの液体がかからないよう注意してください。
- ・ 適切に使用しないと、故障の原因になるおそれや人や物に害が及ぶおそれがあります。
- ・ お子さまが本製品で遊ばないようにご注意ください。
- ・ コンセントは、必ず本製品の設置場所の近くにある、利用しやすいものをお使いください。

お手入れ方法

お手入れの際は、コンセントから電源プラグを抜いて、乾いた布で拭いてください。

使用上の注意

使用しないときは、必ず延長コードの電源プラグをコンセントから抜いてください。

テクニカルデータ

型式：HORNFELS

タイプ：E2309-JP

125 V ~ 60 Hz 15 A 最大 1500 W



「Crossed-out wheeled bin」マークは、廃棄する際に一般の家庭ゴミと区別する必要があることを意味しています。このマークの付いた製品は、お住まいの地域の分別ルールに従ってリサイクルに出してください。一般の家庭ゴミと分けてリサイクルすることで、焼却炉やゴミ埋め立て施設に持ち込まれるゴミの量を削減できるうえ、健康や環境への潜在的な負荷を軽減できます。詳しくは、お近くのイケアストアにお問い合わせください。

English



Read instructions carefully and keep for future reference.

IMPORTANT!

- Do not connect after each other in a sequence.
- Do not cover the product when in use.
- To disconnect the power, pull the plug.
- Use only indoors in dry areas.

WARNING

- Discard the product if damaged.
- Only operate when uncoiled due to increased temperature load.
- Do not overload the product.
- Never submerge in water or other liquids.
- Improper use may cause damage to the product or endanger people or property.
- Children should be supervised to ensure they do not play with the product.
- The wall socket must be located near the equipment and must be easily accessible.

Care instructions

To clean the product, unplug from power source and wipe with a dry cloth.

Good to know

Unplug the extension cord from the power source when not in use.

Technical data

Model: HORNFELS

Type: E2309-JP

125V ~ 60Hz 15A Max. 1500W



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.

