

SMÅHAGEL



Design and Quality
IKEA of Sweden

AA-2606153-1

© Inter IKEA Systems B.V. 2025

한국어



꼼꼼하게 읽은 후 나중에 참고
할 수 있도록 잘 보관해주세요.

제품 용도

SMÅHAGEL 스모하겔 전원공급장치 키트에는 USB-A 충전기 1개, USB-A to USB-C 2 m 케이블 1개가 들어 있습니다. 이케아 장식용 조명과 LED 스폿조명에 전원을 공급하도록 설계되었습니다.

충전기 기능

- USB 포트는 최대 1.0A의 출력을 지원할 수 있습니다.

제품 사용법

벽 콘센트에 전원 어댑터를 연결합니다. 전원 어댑터의 USB 포트에 USB-A 케이블 단

자를 꽂은 후, 충전하거나 전원을 공급할
기기에 케이블의 반대쪽 단자를 꽂아줍니다.

알아두면 좋은 정보

- USB 케이블의 길이와 품질에 따라 충전 속도와 효율이 달라질 수 있습니다.
- 충전 시 장치가 뜨거워질 수 있습니다. 완전히 충전된 후에는 서서히 온도가 내려갑니다.
- 충전기 작동 온도: 5° C~45° C (41° F~113° F).
- 청소하기 전과 사용하지 않을 때는 전원에서 충전기를 분리합니다.
- 충전기는 마른 천으로 닦아주세요.

경고

- 손상된 제품은 폐기하세요.
- 습기가 없는 곳에서만 사용하세요.
- 물이나 액체에 담그지 마세요.

- 어린이가 본 제품을 가지고 놀지 않도록 주의해주세요.
- 어린이가 제품을 가지고 놀지 않도록 주의해주세요.
- 손상되거나 결함이 있는 USB 케이블을 사용하면 충전기나 기기가 고장 나거나 손상될 수 있으므로 절대 사용하지 마세요.

제품 사양

유형: ICPSW5-5KR-1

입력: 100-240 VAC, 50/60 Hz,
최대 0.2 A, 7.0 W

출력: 5.0 VDC, 최대 1.0 A, 5.0 W

실내용

제조업체: IKEA of Sweden AB

주소: Box 702, SE-343 81 Älmhult,
SWEDEN



바퀴달린 통과 엑스표시는 제품을 일반 가정용 쓰레기와는 분리하여 배출해야 한다는 것을 알려주는 표시입니다. 거주 지역의 분리 배출관련 환경 규정에 따라 재활용을 해야 하는 제품입니다. 이렇게 표시된 제품들을 일반 가정용 쓰레기와 구분하는 작업을 통해, 소각장이나 매립지로 보내는 쓰레기의 양을 줄이는 데 기여하고, 인류의 건강과 환경에 미치는 잠재적인 악영향을 최소화할 수 있습니다. 자세한 사항은 이케아 매장으로 문의해 주세요.

English



Read instructions carefully and keep for future reference.

Intended use

SMÅHAGEL power supply kit includes 1 USB-A charger and 1 USB-A to USB-C 2 m cable. It is designed to power IKEA decorative lighting and LED spotlights.

Charger features

- The USB outlet can provide up to 1.0 A load.

Instructions for use

Connect the power adapter into the wall socket. Insert the USB-A cable end into the USB outlet on the power adapter and the other end into the device you want to charge or power.

Good to know

- USB cable length and quality influences charging speed and performance.

- Devices may get warm during charging and will gradually cool down again after they are fully charged.
- Charger operating temperature: 5° C to 45° C (41° F to 113° F).
- Unplug the charger from the power source before cleaning and when it is not in use.
- To clean the charger, wipe with a soft dry cloth.

WARNING

- Discard the product if damaged.
- Only use in dry locations.
- Never submerge in water or other liquids.
- Children should be supervised to ensure they do not play with the product.
- Never use a damaged or faulty USB cable, since this can damage or harm the charger or your device.
- The wall socket must be located near the equipment and must be easily accessible.

Technical data

Type: ICPSW5-5KR-1

Input: 100-240 VAC, 50/60 Hz,
Max. 0.2 A, 7.0 W

Output: 5.0 VDC, Max 1.0 A, 5.0 W

Indoor use only

Manufacturer: IKEA of Sweden AB

Address:

Box 702, SE-343 81 Älmhult, SWEDEN



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.