

MÅLA



Design and Quality
IKEA of Sweden

English

3

عربي

4

English

How to use

For use on whiteboards; the lifespan of the pen will decrease if used on paper.

Store horizontally. If the colour becomes less intense, store the pen vertically with the tip pointed down for 12 hours and the colour will revive.

The whiteboard pen will leave permanent marks on most surfaces and materials, however, immediately washing the area with a stain remover may give good results.

Always protect children's clothes and the surrounding floor etc.

عربي

طريقة الإستخدام

للإستخدام على السبورات البيضاء؛ العمر الإفتراضي للقلم سوف يقل إذا استخدم على الورق.

خزني على وضعية أفقية. إذا أصبح اللون أقل كثافة، خزني القلم على وضعية عمودية بحيث يكون رأسه للأسفل لمدة 12 ساعة وسوف يستعيد اللون كثافته.

قلم السبورة البيضاء سوف يخلف علامات دائمة على معظم الأسطح والمواد، مع ذلك، فإن الغسل الفوري للمكان بمزيل البقع قد يعطي نتائج جيدة.

تأكدي دائماً من وقاية ملابس الأطفال والأرضية المحيطة.