

Bathroom showers

DESIGN

H Preutz/N Karlsson

CARE INSTRUCTIONS

Clean with a soft cloth dampened with water and a mild dish detergent or soap. Never use scouring powder, steel wool or a detergent that is calcium dissolving, sour or contains alcohol or an abrasive. Rinse with water and dry/polish with a clean dry cloth. To remove larger limescale deposits – use diluted, ordinary white vinegar and rinse with water.

GOOD TO KNOW


Wall fittings are provided with the product. If you are uncertain about the installation, contact a professional. The installation shall be made in accordance with valid local building and plumbing regulations.

SAFETY

The thermostatic mixer is pre-set to a safety stop temperature of 100°F. Since operating conditions in each supply system varies, it might be necessary to calibrate the mixer according to the service and installation instructions.



All thermostatic shower mixers include a free 10-year limited warranty. All the riser rails, head/hand showers and hoses include a 3-year limited warranty. For details see IKEA-USA.com/warranty



Everyone deserves a refreshing shower


The IKEA showers are fully coordinated, with everything you need for a great shower experience: thermostatic mixers, head and hand showers with different spray functions and bathroom accessories, all in the same family. All IKEA showers are equipped with water and energy-efficient shower heads and hand showers. This is achieved by having a flow regulator, which reduces the water flow. You'll save up to 30% water and energy compared to a shower without a flow regulator. Everyone deserves a refreshing shower experience every day. What can be more revitalizing than knowing you can save water (and money on your water and energy bills) at the same time? Just pick and choose the shower function you need in your bathroom.

A high standard of accuracy has been sought in the preparation of this buying guide. We apologize for, but will not be bound by or responsible for, errors and omissions in this buying guide.

Not all products may be available in all stores. See what is available at your local store by visiting IKEA-USA.com/stockavailability. For more detailed product information, see the price tag or visit IKEA-USA.com. All products shown require assembly.




HOW TO CHOOSE



1. Here are a few practical steps to help you choose the right product for a great shower experience. Before the purchase consider what shower needs you have in your bathroom. Do you need to refresh an existing shower set? Then you may choose a riser rail with hand shower kit and wall outlet. All IKEA riser rail kits are compatible with any shower mixer of another manufacturer. The shower kits come in three different families - VALLAMOSSE, BROGRUND and VOXNAN just pick the one that suits your style and bathroom best.
2. In case if you want to revitalize your existing shower you can choose to change the hand shower or the shower hose. IKEA shower series offer a wide variety of head and hand showers that come with different spray functions. You can choose between 1, 3 and 5 spray function heads. The head/hand shower with full spray function gives a wide and even coverage for a relaxing shower experience. The mesh spray function boosts the force of the water spray which is perfect for rinsing thick hair. The massage spray function varies the water flow from soft to hard for an invigorating experience that takes away the tension. The mist spray function produces fine droplets of water that feel gentle, soft and relaxing. On 3-spray head shower you can choose between full spray or mesh spray or you can combine the two, giving you the best of both worlds. With the 5-spray head/hand shower you can alternate between full, mist or massage sprays, or choose your favorite combination of full/mist or full/massage, giving you even more alternatives for a relaxing shower.
3. Finally, if you are planning to update your entire shower area then you can choose one of the IKEA thermostatic shower sets that includes all the functions you need for a de-stressing and relaxing shower experience. IKEA shower sets include thermostatic shower and bath/shower mixers so they are a perfect fit both for a bath tub and shower walls. You can complete your new shower with faucets and towel accessories from the same product family for a full style coordination of your bathroom. BROGRUND and VOXNAN series feature a complete range of showers, faucets and bathroom accessories that will make your bathroom uniquely you.

ALL PARTS AND PRICES

All thermostatic shower mixers include a free 10-year limited warranty and all the riser rails, head/hand showers and hoses include a free 3-year limited warranty. For details see IKEA-USA.com/warranty



VALLAMOSSE Riser rail with hand shower and wall outlet
Hand shower Ø3¼". Riser rail H24½".
Chrome-plated finish 703.519.33 **\$24.99**




VALLAMOSSE Single-spray hand shower
Hand shower Ø3¼".
Chrome-plated finish 503.519.34 **\$7.99**



BROGRUND Shower set with thermostatic mixer
Head shower Ø3½". Thermostatic faucet Ø7".
Chrome-plated finish 103.426.25 **\$89**



BROGRUND Bath/shower set with thermostatic mixer
Shower head Ø3½". Thermostatic faucet Ø7". Spout D6½".
Chrome-plated finish 903.426.26 **\$99**



BROGRUND Riser rail with hand shower and wall outlet
Hand shower Ø3½". Riser rail height 25½".
Chrome-plated finish 503.426.28 **\$49.99**



BROGRUND Single-spray shower head with arm
Shower head Ø7¾". D21¼".
Chrome-plated finish 503.858.73 **\$29.99**



BROGRUND 3-spray shower head
Shower head Ø3½".
Chrome-plated finish 703.426.27 **\$14.99**




BROGRUND 5-spray shower head
Shower head Ø4".
Chrome-plated finish 003.517.95 **\$19.99**




BROGRUND 5-spray hand shower
Hand shower Ø4".
Chrome-plated finish 603.517.97 **\$19.99**



VOXNAN Shower set with thermostatic mixer
Head shower Ø3½". Thermostatic faucet Ø7".
Chrome-plated finish 803.426.22 **\$89**



VOXNAN Bath/shower set with thermostatic mixer
Head shower Ø3½". Thermostatic faucet Ø7". Spout D6½".
Chrome-plated finish 003.426.21 **\$99**



VOXNAN Riser rail with hand shower and wall outlet
Hand shower Ø3½". Riser rail H26¾".
Chrome-plated finish 603.426.23 **\$49.99**



VOXNAN Single-spray shower head with arm
Shower head Ø7¾". D21¼".
Chrome-plated finish 403.724.23 **\$29.99**



VOXNAN 3-spray shower head
Shower head Ø3½".
Chrome-plated finish 403.426.24 **\$14.99**



VOXNAN 5-spray shower head
Shower head Ø4".
Chrome-plated finish 203.517.99 **\$19.99**




VOXNAN 5-spray hand shower
Hand shower Ø4¼".
Chrome-plated finish 603.518.01 **\$19.99**




KOLSJÖN Shower hose L59".
Chrome-plated finish 803.518.00 **\$12.99**

FAUCETS AND TOWEL ACCESSORIES

All bathroom faucets have 10-year Limited Warranty.



VOXNAN Tall faucet H11¾".
 Chrome-plated brass 603.430.62 **\$89.99**



BROGRUND Tall faucet H11".
 Chrome-plated brass 003.430.98 **\$79.99**




VOXNAN Faucet H7½".
 Chrome-plated brass 303.430.92 **\$79.99**



BROGRUND Faucet H6¾".
 Chrome-plated brass 503.430.86 **\$69.99**



VOXNAN Towel rail L24¾".
 Chrome-plated finish 603.285.99 **\$12.99**



BROGRUND Towel rail L26½".
 Stainless steel 303.285.34 **\$12.99**



VOXNAN Towel holder, 3 bars Extendable bars.
 L17¾-25½".
 Stainless steel/
 chrome-plated zinc 003.285.97 **\$14.99**




BROGRUND Towel holder, 3 bars Extendable bars.
 L17-24¾".
 Stainless steel 604.267.07 **\$16.99**



VOXNAN Knobs
 Chrome-plated finish 203.285.82 **\$5.99/2pk**



BROGRUND Hooks
 Stainless steel 603.285.42 **\$3.99/2pk**



BROGRUND Extendable towel stand
 W48¾-61×H33".
 Stainless steel 304.089.98 **\$24.99**



BROGRUND Corner wall shelf unit W7½×D7½×H22¾".
 Stainless steel 304.089.79 **\$14.99**