BRIMNES



Design and Quality
IKEA of Sweden

English

WARNING!

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

Français

ATTENTION !

Enfants morts suite au basculement de meuble. Afin de limiter le risque de basculement d'un meuble :

- TOUJOURS utiliser les fixations anti-basculement fournies.
- NE JAMAIS installer de TV sur ce produit.
- NE JAMAIS laisser d’enfants se tenir debout sur les tiroirs, portes ou étagères, y grimper ou s’y suspendre.
- NE JAMAIS ouvrir plus d’un tiroir à la fois.
- Placer les choses les plus lourdes dans les tiroirs du bas.

Español

¡ADVERTENCIA!

Han muerto niños por el vuelco de muebles. Para limitar el riesgo de vuelco de los muebles:

- Utilizar SIEMPRE las fijaciones antivuelco que se suministran.
- NUNCA instalar un TV sobre este producto.
- NUNCA permitir que los niños se pongan de pie, trepen o se cuelguen de los cajones, puertas o baldas.
- NUNCA abrir más de un cajón a la vez.
- Colocar los objetos más pesados en los cajones inferiores.

AA-2395783-4


Ø 5/16"
(8 mm)
Ø 1/8"
(3 mm)
Ø 5/16"
(8 mm)
Ø 5/16"
(8 mm)
Ø 1/8"
(3 mm)


lb






IKEA


109567
10087223
109049
100823
106989
27
2x
2x
2x
4x
2x
370766



4x



14x



6x



3x



22x

14x



49x



60x



1x



3x



8x



2x



3x



12x



2x



1x



157306
157307
10121089

2x



109336

9x



109220

9x



124328
128763
145915
10121200

3x



122663
119543
10121128

1x

1



2



3



4



5



6



7



8



9



10



11



12



13



14



15



16



17



18



19



20



21



22



23



24



25



26



27



28



29



30





31



32



33



34



35





36









37

x

x



www.IKEA.com/secure-it



38

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

Français

Les vis et les chevilles fournies peuvent être utilisées avec la plupart des murs pleins (A) ou des murs creux (B). Pour le bois massif (C), utiliser les vis sans les chevilles. En cas de doute, adressez-vous à un professionnel qualifié.

Español

Los tornillos y tacos incluidos se pueden utilizar en la mayor parte de las paredes sólidas (A) o huecas (B). Para la madera maciza (C), usa los tornillos sin tacos. Si tienes dudas, acude a un experto.



39



40



41





42



43



44



45



46



47






B
A
B
A
B
A




B
A
B
A
B
A




B
A

© Inter IKEA Systems B.V. 2023
2024-02-28 AA-2395783-4