




HAUGA



Design and Quality
IKEA of Sweden



English

WARNING!

Children have died from furniture tipover.

To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.





NEVER open more than one drawer at a time.

DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system.

Place heaviest items in the lowest drawers.

Read and follow each step of the instruction carefully.






1



101345


12x



151706

151708


10x



151705

151707

10x



10093081

6x



10093082

6x




105811

8x




146114

36x



153548
158568


2x



10040039
10051022


4x

A



118331

24x




119976

12x



146114

36x



145718


159553

24x



101345

20x




119030

118224


120076

48x




10052019

12x




10040242

6x




109572

2x



10087223


2x




10102070

2x


370172




1




2




3




4




5




6




7




8




9




10




11




12




13




14




15






16







17






18



19


x

x






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



20




English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.




A
Ø 8 mm (5/16")
1
2
3





B
Ø 8 mm (5/16")
1
2
3



C
Ø 3 mm (1/8")
1
2
3





21















24




25





26






27


28





29





30





31




32




33




34




35






1



2



3

