


JONAXEL



Design and Quality
IKEA of Sweden



English

WARNING

**Children have died from furniture
tipover. To reduce the risk of furniture
tipover:**

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on
any drawers, doors, or shelves.


NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction
carefully.






10004344
10042533

2x




124461
130520

2x




10003068
10042581

4x



10003467
10042570



2x




10004342

1x




1






2





3






4








5






i



3 mm
(1/8")






i






10 mm
(3/8")










6






7




10004344
10042533






8







i





3 mm
(1/8")





i



i



2x



i

