





# LASTARE



Design and Quality  
IKEA of Sweden



English

## WARNING!

**Children have died from furniture tipover.**

**To reduce the risk of furniture tipover:**

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

NEVER open more than one drawer at a time.

DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system.





Place heaviest items in the lowest drawers.





Read and follow each step of the instruction carefully.






[www.IKEA.com/secure-it](http://www.IKEA.com/secure-it)

	A	B	C
	Ø 5/16" (8 mm)	Ø 5/16" (8 mm)	Ø 1/8" (3 mm)











10130526  
10128892

3x






10127696  
10119463

1x




10123365  
10123376




1x




1





2




4x




# 3




4x




4




5






6





7




8







9








# 10






11








12




13




# 14







# 15




16




17





# 18




# 19








# 21










# 22




# 23









25






26




27






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



# 28

## English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

**A**

**Ø 8 mm (5/16")**

**1**

70 mm (2 3/4")

**2**

31

**B**

**Ø 8 mm (5/16")**

**1**

≈ 30 mm (≈ 1 1/4")

**2**

32


**C**

**Ø 3 mm (1/8")**

**1**


≈ 30 mm (≈ 1 1/4")

34







**29**

x




**30**








**29**



30






29



x






x


2x




# 31









32




33






34




# 35




# 36




# 37




# 38






# 39




# 40





# 41





# 42



43



44



# 45

