





STOREMOLLA



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.



NEVER open more than one drawer at a time.







DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.







1




18x



18x




20x




4x




32x




18x




18x



5x




11x




1x


2




32x




32x



32x




4x




8x




32x




32x




8x




1x




1




2




3




4




5




6




7







9




10




11




12







14




15







17




18




19




20




21






23

18x








24

5x







25






26

2x








www.IKEA.com/secure-it



www.IKEA.cn/secure-it



28

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


A




Ø 8 mm
(5/16")




1




2



3




B




Ø 8 mm
(5/16")




1




2



3




C




Ø 3 mm
(1/8")









1




2




29






30









31




32








33






33










34










36









38







39




40




41










42




43




44







45




46






47








2x



1



2



3

