









ASKVOLL




Design and Quality
IKEA of Sweden




2



20x




20x



20x




20x




10x




20x





5x




5x











1




2









5




6




7



8



9





⚠ WARNING	⚠ ATTENTION	⚠ ADVERTENCIA
Children have died from furniture tipping, particularly if the child is under 6 years of age. • Always use the correct assembly procedure. • NEVER use children as steps, ladders or seats. • NEVER open more than one drawer at a time. • Place weights firmly in the lower drawers. This is a permanent label, do not remove.	Enfants morts suite au basculement d'un meuble, particulièrement si l'enfant a moins de 6 ans. • TOUJOURS utiliser les bonnes procédures d'assemblage. • NE JAMAIS utiliser des enfants comme échelles, pour grimper ou s'asseoir. • NE JAMAIS ouvrir plus d'un tiroir à la fois. • Placez les poids au fond des tiroirs. Information permanente, ne pas retirer.	Nun meubels mehr für ein Kind zu gefährden, besonders wenn das Kind unter 6 Jahren ist. • Immer benutzen die richtigen Anbauverfahren. • NIEMALS benutzen ein Kind als Leiter, um zu klettern oder zu sitzen. • NIEMALS mehr als ein Schrankfach gleichzeitig öffnen. • Setzen Sie die Gewichte in die unteren Schrankfächer. Dies ist ein permanenter Aufkleber, nicht abheben!

