


VIHALS



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.

יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.





על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:





- מקמו את הפריטים הכבדים ביותר במגירה התחתונה.
- הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.
- אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.













1




10077982

4x



151707

10x



151708

10x




10051660

10102154

10107001

16x




10093081

6x



10093082

6x




10005905

10099750

10106990

2x




10061178

10100254


10107020

6x




100092

1x




2




4x

150521
192164
10100431




4x

192157
192165
10100439




2x

192160
192168
10107466



2x

192159
192167
10107465




20x

192158
192166
10100430




4x

146114




4x

109535
116560




1x

100049



2x

192161
192169
10100429




2x

10078838
10099766
10106966





28



2x


157976
10100089
10108121



2x


157975
10100091
10108120






150689

2x




126916

2x




150688

2x




147968

2x



158469

2x



121714


2x




16

327495


1







2




3




4




5




6




7





8





9








10






11







13



14






English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




Ø 8 mm
(5/16")



1




2




70 mm
(2 3/4")

3




B




Ø 8 mm
(5/16")



1




2




≈ 30 mm
(≈ 1 1/4")

3




C




Ø 3 mm
(1/8")



1





2







≈ 30 mm
(≈ 1 1/4")



3









↕
15







⇅
15





16



17























157976
10100089
10108121


20




21















25





26



27

