


Buying guide

SEGERÖN

Outdoor, living furniture series



Outdoor, furniture can make everyday life more enjoyable

The SEGERÖN series is carefully designed with outdoor, conditions in mind, considering all types of weather, climate and activities. With SEGERÖN outdoor, furniture, you can enjoy the luxury feel of the time spent in it – without spending a fortune on it.

Easy to care for

This product is durable and easy to care for, since it's made of a powder-coated steel frame and rope that is handwoven onto the product.

A high standard of accuracy has been sought in the preparation of this buying guide. We apologize for, but will not be bound by or responsible for, errors and omissions in this buying guide.

Not all products may be available in all stores. See what is available at your local store by visiting [IKEA-USA.com/stockavailability](https://www.ikea-usa.com/stockavailability). For more detailed product information, see the price tag or visit [IKEA-USA.com](https://www.ikea-usa.com). All products shown require assembly. All textiles shown are imported.



Seating combinations



SEGERÖN Armchair Outdoor.
Dark green/FRÖSÖN/DUVHOLMEN multicolor stripe.
This combination 795.330.38

SEGERÖN Armchair Outdoor. Dark green	105.147.54	1 pc
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Multicolor stripe pattern	805.471.76	1 pc
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	1 pc



SEGERÖN Armchair Outdoor.
Dark green/FRÖSÖN/DUVHOLMEN beige.
This combination 095.008.09

SEGERÖN Armchair Outdoor. Dark green	105.147.54	1 pc
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Beige	103.917.10	1 pc
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	1 pc



SEGERÖN Armchair Outdoor.
Dark green/FRÖSÖN/DUVHOLMEN dark gray.
This combination

SEGERÖN Armchair Outdoor. Dark green	105.147.54	1 pc
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Dark gray	103.917.48	1 pc
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	1 pc



SEGERÖN Armchair Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.
This combination 195.008.18

SEGERÖN Armchair Outdoor. White/beige	505.108.10	1 pc
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Beige	303.917.47	1 pc
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	1 pc



SEGERÖN Table + four armchairs Outdoor.
Dark green/FRÖSÖN/DUVHOLMEN multicolor stripe.
This combination 295.329.65

SEGERÖN Table, Outdoor. W35%×L57%". Dark green/light gray	105.108.12	1 pc
SEGERÖN Armchair, Outdoor. Dark green	105.147.54	4 pcs
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Multicolor stripe pattern	805.471.81	4 pcs
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	4 pcs



SEGERÖN Table + four armchairs Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.
This combination 395.008.41

SEGERÖN Table, Outdoor. W35%×L57%". White/beige	905.108.13	1 pc
SEGERÖN Armchair, Outdoor. White/beige	505.108.10	4 pcs
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Beige	303.917.47	4 pcs
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	4 pcs

Seating combinations



SEGERÖN Table + four armchairs Outdoor.
Dark green/FRÖSÖN/DUVHOLMEN beige.

This combination 995.008.24

SEGERÖN Table, Outdoor. W35%×L57%". Dark green/light gray	105.108.12	1 pc
SEGERÖN Armchair Outdoor. Dark green	105.147.54	4 pcs
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Beige	303.917.47	4 pcs
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	4 pcs



SEGERÖN Table + four armchairs Outdoor.
Dark green/FRÖSÖN/DUVHOLMEN dark gray.

This combination

SEGERÖN Table, Outdoor. W35%×L57%". White/beige	105.108.12	1 pc
SEGERÖN Armchair, Outdoor. Dark green	105.147.54	4 pcs
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Dark gray	103.917.48	4 pcs
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	4 pcs



SEGERÖN Table + six armchairs Outdoor.
Dark green/FRÖSÖN/DUVHOLMEN multicolor stripe.

This combination 495.329.69

SEGERÖN Table, Outdoor. 35%×83½". Dark green/light gray	005.107.99	1 pc
SEGERÖN Armchair, Outdoor. Dark green	105.147.54	6 pcs
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Multicolor stripe pattern	805.471.81	6 pcs
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	6 pcs



SEGERÖN Table + six armchairs Outdoor.
Dark green/FRÖSÖN/DUVHOLMEN dark gray.

This combination

SEGERÖN Table, Outdoor. 35%×83½". Dark green/light gray	005.107.99	1 pc
SEGERÖN Armchair, Outdoor. Dark green	105.147.54	6 pcs
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Dark gray	103.917.48	6 pcs
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	6 pcs



SEGERÖN Table + six armchairs Outdoor.
Dark green/FRÖSÖN/DUVHOLMEN beige.

This combination 095.090.70

SEGERÖN Table, Outdoor. 35%×83½". Dark green/light gray	005.107.99	1 pc
SEGERÖN Armchair, Outdoor. Dark green	105.147.54	6 pcs
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Beige	303.917.47	6 pcs
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	6 pcs



SEGERÖN Table + six armchairs Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.

This combination 995.008.57

SEGERÖN Table, Outdoor. W35%×L57%". White/beige	105.108.07	1 pc
SEGERÖN Armchair, Outdoor. White/beige	505.108.10	6 pcs
FRÖSÖN Cover chair cushion, 17%×17%". Outdoor. Beige	303.917.47	6 pcs
DUVHOLMEN Inner cushion chair cushion, 17%×17%". Outdoor.	703.918.49	6 pcs

Seating combinations



SEGERÖN Bar table + two swivel bar stools Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.

This combination

SEGERÖN Bar table, Outdoor. 35×35×41¾". White/beige	605.108.00	1 pc
SEGERÖN Bar stool, swivel, Outdoor. White/beige	905.033.46	2 pcs
FRÖSÖN Cover chair cushion, Outdoor. Ø13¾". Beige	503.917.46	2 pcs
DUVHOLMEN Inner cushion chair cushion, Outdoor. Ø13¾".	003.918.43	2 pcs



SEGERÖN Bar table + two bar stools Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.

This combination

SEGERÖN Bar table, Outdoor. 35×35×41¾". White/beige	605.108.00	1 pc
SEGERÖN Bar stool, Outdoor. White/beige	905.108.08	2 pcs
FRÖSÖN Cover chair cushion, 17¾×17¾". Outdoor. Beige	303.917.47	2 pcs
DUVHOLMEN Inner cushion chair cushion, 17¾×17¾". Outdoor.	703.918.49	2 pcs



SEGERÖN Bar table + four swivel bar stools Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.

This combination


SEGERÖN Bar table, Outdoor. 35×35×41¾". White/beige	605.108.00	1 pc
SEGERÖN Bar stool, swivel, Outdoor. White/beige	905.033.46	4 pcs
FRÖSÖN Cover chair cushion, Outdoor. Ø13¾". Beige	503.917.46	4 pcs
DUVHOLMEN Inner cushion chair cushion, Outdoor. Ø13¾".	003.918.43	4 pcs



SEGERÖN Bar table + four bar stools Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.

This combination


SEGERÖN Bar table, Outdoor. 35×35×41¾". White/beige	605.108.00	1 pc
SEGERÖN Bar stool, Outdoor. White/beige	905.108.08	4 pcs
FRÖSÖN Cover chair cushion, 17¾×17¾". Outdoor. Beige	303.917.47	4 pcs
DUVHOLMEN Inner cushion chair cushion, 17¾×17¾". Outdoor.	703.918.49	4 pcs



SEGERÖN Loveseat conversation set Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.

This combination

SEGERÖN Corner section, Outdoor. White/beige	705.108.09	2 pcs
FRÖSÖN Cover seat cushion, Outdoor. 24¾×24¾". Beige	903.917.49	1 pc
DUVHOLMEN Inner cushion seat cushion, Outdoor. 24¾×24¾".	403.918.55	2 pcs
FRÖSÖN Cover back cushion, Outdoor. 24¾×17¾". Beige	203.917.43	2 pcs
DUVHOLMEN Inner cushion back cushion, Outdoor. 24¾×17¾".	003.918.38	2 pcs
SEGERÖN Coffee table, Outdoor. 28¾×28¾". White/beige	405.107.97	1 pc




SEGERÖN 3-seat conversation set Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.

This combination 095.014.46


SEGERÖN One-seat section, Outdoor. White/beige	505.108.05	3 pcs
SEGERÖN Corner section, Outdoor. White/beige	705.108.09	1 pc
FRÖSÖN Cover seat cushion, Outdoor. 24¾×24¾". Beige	903.917.49	4 pcs
DUVHOLMEN Inner cushion seat cushion, Outdoor. 24¾×24¾".	403.918.55	4 pcs
FRÖSÖN Cover back cushion, Outdoor. 24¾×17¾". Beige	203.917.43	5 pcs
DUVHOLMEN Inner cushion back cushion, Outdoor. 24¾×17¾".	003.918.38	5 pcs
SEGERÖN Coffee table, Outdoor. 28¾×28¾". White/beige	405.107.97	1 pc

Seating combinations




SEGERÖN Corner sofa Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.
This combination

SEGERÖN Corner section, Outdoor. White/beige	705.108.09	1 pc
SEGERÖN One-seat section, Outdoor. White/beige	505.108.05	3 pcs
FRÖSÖN Cover seat cushion, Outdoor. 24¾×24¾". Beige	903.917.49	4 pcs
DUVHOLMEN Inner cushion seat cushion, Outdoor. 24¾×24¾".	403.918.55	4 pcs
FRÖSÖN Cover back cushion, Outdoor. 24¾×17¾". Beige	203.917.43	5 pcs
DUVHOLMEN Inner cushion back cushion, Outdoor. 24¾×17¾".	003.918.38	5 pcs
SEGERÖN Coffee table, Outdoor. 28¾×28¾". White/beige	405.107.97	1 pc




SEGERÖN/LÅGASKÄR Corner conversation set Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.
This combination 595.014.63

SEGERÖN One-seat section Outdoor. White/beige	505.108.05	3 pcs
SEGERÖN Corner section Outdoor. White/beige	705.108.09	1 pc
FRÖSÖN Cover seat cushion, Outdoor. 24¾×24¾". Beige	903.917.49	4 pcs
DUVHOLMEN Inner cushion seat cushion, Outdoor. 24¾×24¾".	403.918.55	4 pcs
FRÖSÖN Cover back cushion, Outdoor. 24¾×17¾". Beige	203.917.43	5 pcs
DUVHOLMEN Inner cushion back cushion, Outdoor. 24¾×17¾".	003.918.38	5 pcs
LÅGASKÄR Coffee table, Outdoor. Beige	905.437.62	1 pc



SEGERÖN 5-seat corner conversation set Outdoor.
White/FRÖSÖN/DUVHOLMEN beige.
This combination 795.089.82

SEGERÖN One-seat section, Outdoor. White/beige	505.108.05	5 pcs
SEGERÖN Corner section, Outdoor. White/beige	705.108.09	1 pc
FRÖSÖN Cover seat cushion, Outdoor. 24¾×24¾". Beige	903.917.49	3 pcs
DUVHOLMEN Inner cushion seat cushion, Outdoor. 24¾×24¾".	403.918.55	6 pcs
FRÖSÖN Cover back cushion, Outdoor. 24¾×17¾". Beige	203.917.43	7 pcs
DUVHOLMEN Inner cushion back cushion, Outdoor. 24¾×17¾".	003.918.38	7 pcs
SEGERÖN Coffee table, Outdoor. 28¾×28¾". White/beige	405.107.97	1 pc



SEGERÖN Chaise Outdoor.
White/beige/FRÖSÖN/DUVHOLMEN beige.
This combination 295.008.65

SEGERÖN Chaise, White/beige	205.107.98	1 pc
FRÖSÖN Chaise cushion cover, Outdoor. 74¾×23¾". Beige	005.098.85	1 pc
DUVHOLMEN Inner cushion for chaise pad, Outdoor. 74¾×23¾".	305.099.35	1 pc

All the parts



SEGERÖN Table Outdoor. W35½×L57½×H29½".

Dark green/light gray	105.108.12
White/beige	905.108.13



SEGERÖN Table Outdoor. W35½×L83½×H29½".

Dark green/light gray	005.107.99
White/beige	105.108.07



SEGERÖN Armchair Outdoor. W26¾×D24¾×H28¾".

Dark green	105.147.54
White/beige	505.108.10



SEGERÖN Swivel bar stool Outdoor. W20¾×D20¾×Seat H29¾".

White/beige	905.033.46
-------------	------------



SEGERÖN Bar stool Outdoor. W22×D21¾×Seat H28¾".

White/beige	905.108.08
-------------	------------



SEGERÖN Bar table Outdoor. W35×L35×H41¼".

White/beige	605.108.00
-------------	------------



SEGERÖN Chaise Outdoor. W28¾×L80¾×H15".

White/beige	205.107.98
-------------	------------



SEGERÖN Coffee table Outdoor. W28¾×L28¾×H11¼".

White/beige	405.107.97
-------------	------------



SEGERÖN One-seat section Outdoor. W29¾×D29¾×H27¾".

White/beige	705.108.09
-------------	------------



SEGERÖN Corner section Outdoor. W24¾×D29¾×H27¾".

White/beige	505.108.05
-------------	------------

All the parts

FRÖSÖN cushion covers are sold separately from DUVHOLMEN inner cushions, so it's easier to change the look and wash the cover.



FRÖSÖN Cover for chair cushion Ø13¾\". To be completed with DUVHOLMEN inner cushion for chair cushion Ø13¾\", sold separately.

Beige	503.917.46
-------	------------

DUVHOLMEN Inner cushion for chair cushion Ø13¾\". Thickness 1½\".

White	003.918.43
-------	------------



FRÖSÖN Cover for chair cushion 17¾×17¾\". To be completed with DUVHOLMEN inner cushion for chair cushion 17¾×17¾\", sold separately.

Beige	303.917.47
-------	------------

Dark gray	103.917.48
-----------	------------

Multicolor stripe pattern	805.471.81
---------------------------	------------

DUVHOLMEN Inner cushion for chair cushion 17¾×17¾\". Thickness 2\".

White	804.178.96
-------	------------



FRÖSÖN Cover for seat cushion 24¾×24¾\". To be completed with DUVHOLMEN inner cushion for seat cushion 24¾×24¾\", sold separately.

Beige	903.917.49
-------	------------

Dark gray	703.917.50
-----------	------------

DUVHOLMEN Inner cushion for seat cushion. 24¾×24¾\". Thickness 5½\".

White	403.918.55
-------	------------



FRÖSÖN Cover for back cushion. 24¾×17¾\". To be completed with DUVHOLMEN inner cushion for back cushion 24¾×17¾\", sold separately.

Beige	203.917.43
-------	------------

Dark gray	003.917.15
-----------	------------

DUVHOLMEN Inner cushion for back cushion 24¾×17¾\". Thickness 5½\".

White	003.918.38
-------	------------

JÄRPÖN cushion covers are sold separately from DUVHOLMEN inner cushions, so it's easier to change the look and wash the cover.




JÄRPÖN Cover for seat cushion 17¾×17¾\".

To be completed with DUVHOLMEN inner cushion 17¾×17¾\", sold separately.

White	404.835.34
-------	------------

DUVHOLMEN Inner cushion for seat cushion 17¾×17¾\". Thickness 2\". To be completed with FRÖSÖN or JÄRPÖN cover for seat cushion 17¾×17¾\", sold separately.

White	703.918.49
-------	------------



JÄRPÖN Cover for seat cushion 24¾×24¾\".

To be completed with DUVHOLMEN inner cushion 24¾×24¾\", sold separately.

White	104.453.22
-------	------------

Anthracite	204.453.31
------------	------------

DUVHOLMEN Inner cushion for seat cushion 24¾×24¾\". Thickness 5½\". To be completed with FRÖSÖN or JÄRPÖN cover for seat cushion 24¾×24¾\", sold separately.

White	403.918.55
-------	------------



JÄRPÖN Cover for back cushion 24¾×17¾\". To be completed with DUVHOLMEN inner cushion 24¾×17¾\", sold separately.

White	604.452.92
-------	------------

Anthracite	504.453.01
------------	------------

DUVHOLMEN Inner cushion for back cushion 24¾×17¾\". Thickness 5½\". To be completed with FRÖSÖN or JÄRPÖN cover for back cushion 62×44 cm. Sold separately.

White	003.918.38
-------	------------



FRÖSÖN Chaise cushion cover L75×W24\". To be completed with DUVHOLMEN inner cushions for chaise cushion. Sold separately.

Beige	005.098.85
-------	------------

Dark gray	105.099.03
-----------	------------

DUVHOLMEN inner cushion for chaise pad L75×W24\". Thickness 2\".

White	305.099.35
-------	------------

Protecting and caring for SEGERÖN

The best way to extend the life of your wooden outdoor furniture is by cleaning it regularly, not leaving it outdoors unprotected more than necessary and to re-stain it on a regular basis.

Cleaning

Wipe clean with a soft cloth dampened in water and a mild soapy solution. Wipe dry with a clean and dry cloth.

Maintenance

To prevent the surface from drying out and cracking and moisture from penetrating into the wood we recommend you to re-stain the furniture on a regular basis, for example once a year. How often you will need to do this will depend on how exposed the furniture is to the wear and tear. For furniture that stands in the open air, a good indication that you need to re-stain is if raindrops are absorbed directly into the wood and no longer form small beads on the surface.

Storing

If possible, store your outdoor furniture in a cool and dry place indoors off season. If the furniture is left outdoors, make sure to protect it with a waterproof cover and if possible tilt the furniture to make it easier for any water to drain away. After a rain or snowfall, wipe off excess water or snow from flat surfaces. Allow air to circulate, to avoid condensation.

TOSTERÖ waterproof furniture covers

Covers for dining sets



TOSTERÖ Cover for furniture set Fits outdoor dining sets with a table and two chairs. Black
W25%×L47%×H47%". 905.323.39



TOSTERÖ Cover for furniture set Fits outdoor bar sets with a bar table and as many as four bar stools. Black
W31½×L74¾80×H47%". 705.323.40



TOSTERÖ Cover for furniture set Fits outdoor dining sets with a table and as many as four chairs. Black
W57%×L57%×H47%". 803.050.64



TOSTERÖ Cover for furniture set Fits outdoor dining sets with a table and as many as six chairs. Black
W53%×L84%×H41%". 503.050.65

Storage bags and storage box



TOSTERÖ Storage box A good fit for furniture cushions or decorative cushions when they are not in use. Black
W50¾×L17%×H31%". 304.114.39



VRENEN Storage box Polypropylene plastic. Light gray/gray
W61%×D28×H36%". 504.114.43



VÄTTERSÖ Storage box Outdoor. Dark gray
W61%×D28%×H31%". 805.629.06
W30¾×D28%×H30¾%". 605.629.07



Covers for armchairs and sofas



TOSTERÖ Cover for 2-seat corner sofas and loveseat sets Fits for example outdoor 2-seat corner sofas and a coffee table, or loveseat together with an armchair and a coffee table, with total max W86%×L86%×H33½%". Black
W86%×L86%×H33½%". 605.323.07

Other covers



TOSTERÖ Cover for chaise Fits one chaise with max L81%×W19%×H29½%". Black
W19%×L81%×H29½%". 605.323.26