

Bath faucets and Accessories

CARE INSTRUCTIONS


Clean with a soft cloth dampened with water and a mild dish detergent or soap. Never use scouring powder, steel wool or a detergent that is calcium dissolving, sour or contains alcohol or an abrasive. Rinse with water and dry/polish with a clean dry cloth. To remove larger limescale deposits — use diluted, ordinary white vinegar and rinse with water.

GOOD TO KNOW

Wall fittings are not provided with the product. If you are uncertain about the installation, contact a professional. The installation should be made in accordance with valid local building and plumbing regulations.

SAFETY

The thermostatic faucet is pre-set to a safety stop temperature of 100°F. Since operating conditions in each supply system varies, it might be necessary to calibrate the faucet according to the service and installation instructions.



10

All bath faucets and thermostatic shower faucets include a free 10-year limited warranty. For details see [IKEA.us/warranty](https://www.IKEA.us/warranty)

3

All the riser rails, head/hand showers and hoses include a 3-year limited warranty. For details see [IKEA.us/warranty](https://www.IKEA.us/warranty)

Everyone deserves a refreshing bathroom

IKEA Bath faucets and accessories coordinate with everything you need for a great bath and shower experience: thermostatic faucets, head and hand showers with different spray functions and bathroom accessories, all in the same family. All IKEA showers are equipped with water and energy-efficient shower heads and hand showers. This is achieved by having a flow regulator, which reduces the water flow. You'll save up to 30% water and energy compared to a shower without a flow regulator. Everyone deserves a refreshing shower experience every day. What can be more revitalizing than knowing you can save water (and money on your water and energy bills) at the same time? Just pick and choose the shower function you need in your bathroom.

A high standard of accuracy has been sought in the preparation of this buying guide. We apologize for, but will not be bound by or responsible for, errors and omissions in this buying guide.

Not all products may be available in all stores. See what is available at your local store by visiting [IKEA.us](https://www.IKEA.us). For more detailed product information, see the price tag or visit [IKEA.us](https://www.IKEA.us). All products shown require assembly.



Bath Faucets

All bathroom faucets have a 10-year limited warranty. For details see IKEA.us/warranty



SALJEN Sink faucet Plastic. Height 4 3/4".
 Black 204.003.23



PILKÅN Sink faucet Brass. Height 3 3/8".
 Chrome-plated 205.328.61



ENSEN Sink faucet Brass. Height 4 3/4".
 Chrome-plated 305.325.49



DALSKÅR Sink faucet Brass. Height 7 1/8".
 Chrome-plated 905.325.27



BROGRUND Sink faucet Brass. Height 6 3/4".
 Chrome-plated 205.321.11



BROGRUND Sink faucet with sensor Brass. Height 5 1/8".
 Chrome-plated 804.233.50




BROGRUND Sink faucet, tall Brass. Height 11".
 Chrome-plated 005.320.94



RUNSKÅR Sink faucet Brass. Height 3 3/8".
 Chrome-plated 305.331.53




HAMNSKÅR Sink faucet Brass. Height 7 1/2".
 Chrome-plated 805.327.16




VOXNAN Sink faucet, tall Brass. Height 11 3/4".
 Chrome-plated 605.332.55

Shower Faucets


All thermostatic shower faucets include a free 10-year limited warranty and all the riser rails, head/hand showers and hoses include a free 3-year limited warranty. For details see IKEA.us/warranty



BROGRUND Riser rail with hand shower and wall outlet
Hand shower $\text{\O}3\frac{1}{2}$ ". Riser rail height 25 $\frac{1}{2}$ ".
Chrome-plated finish 503.426.28



BROGRUND Bath/shower set with thermostatic faucet
Shower head $\text{\O}3\frac{1}{2}$ ". Thermostatic faucet $\text{\O}7$ ". Spout D6 $\frac{1}{2}$ ".
Chrome-plated finish 903.426.26



VALLAMOSSE Riser rail with hand shower and wall outlet
Hand shower $\text{\O}3\frac{1}{4}$ ". Riser rail H24 $\frac{1}{2}$ ".
Chrome-plated finish 703.519.33




VOXNAN Bath/shower set with thermostatic faucet
Shower head $\text{\O}3\frac{1}{2}$ ". Thermostatic faucet $\text{\O}7$ ". Spout D6 $\frac{1}{2}$ ".
Chrome-plated finish 003.426.21




LILLREVET Single-spray hand shower
Hand shower $\text{\O}3\frac{1}{4}$ ".
White 503.426.33

ACCESSORIES



BROGRUND Towel rail L26 1/2".
Stainless steel 303.285.34




BROGRUND Hanger for door W11 1/2 x H5 1/2".
Stainless steel 203.285.44



BROGRUND Hooks
Stainless steel 205.246.77 **2pk**



BROGRUND Corner wall shelf unit W7 1/2 x D7 1/2 x H22 3/4".
Stainless steel 304.089.79



BROGRUND Toilet paper holder W5".
Stainless steel 003.285.40



BROFJÄRDEN Soap dish
Chrome-effect 505.815.48



BROFJÄRDEN Wall shelf/towel rail 29 1/2 x 11 3/8".
Chrome-effect 205.822.38



BROFJÄRDEN Bath set
Gray 505.648.84 3pcs




BROFJÄRDEN Towel holder Ø8 1/4".
Chrome-effect 105.822.29



BROFJÄRDEN Towel rail L29 1/4".
Chrome-effect 505.822.32



BROFJÄRDEN Double hook
Chrome-effect 505.822.27



BROFJÄRDEN Shower shelf 13 x 4 3/4".
Chrome-effect 105.822.34



BROFJÄRDEN Toilet brush
Chrome-effect 105.815.50



BROFJÄRDEN Toilet paper holder
Chrome-effect 705.815.52



BROFJÄRDEN Trash can 1 gallon
Chrome-effect 205.821.82




VISSLAÄN Box with compartments, 12 3/4 x 12 1/4 x 3 1/4".
Small compartments practical for sorting items like hair accessories and jewelry.
Brown-beige 005.621.04



VISSLAÄN Boxes with lids Includes: one box (8 x 8 x 3 1/2"), one box (8 x 4 x 3 1/2") and three boxes (4 x 4 x 3 1/2").
Brown-beige 905.545.38 **set of 5**



VISSLAÄN Drawer organizer, 13 3/4 x 4 1/4 x 1".
Brown-beige 405.621.16



VISSLAÄN Drawer organizers
Includes: one tray, (6 1/8 x 3 1/2 x 1"), one bottle holder (6 1/2 x 4 3/8 x 3 1/2") and one toothbrush holder (2 3/4 x 3 3/8 x 4 1/2").
Brown-beige 205.621.17 **set of 3**



VISSLAÄN Hanger for door
Black 406.199.43



VISSLAÄN Hook, self-adhesive
Black 205.918.60



VISSLAÄN Towel hanger, self adhesive
Black 606.145.86