

Bath faucets and Accessories

CARE INSTRUCTIONS


Clean with a soft cloth dampened with water and a mild dish detergent or soap. Never use scouring powder, steel wool or a detergent that is calcium dissolving, sour or contains alcohol or an abrasive. Rinse with water and dry/polish with a clean dry cloth. To remove larger limescale deposits — use diluted, ordinary white vinegar and rinse with water.

GOOD TO KNOW

Wall fittings are not provided with the product. If you are uncertain about the installation, contact a professional. The installation should be made in accordance with valid local building and plumbing regulations.

SAFETY

The thermostatic faucet is pre-set to a safety stop temperature of 100°F. Since operating conditions in each supply system varies, it might be necessary to calibrate the faucet according to the service and installation instructions.



10

All bath faucets and thermostatic shower faucets include a free 10-year limited warranty. For details see IKEA-USA.com/warranty

3

All the riser rails, head/hand showers and hoses include a 3-year limited warranty. For details see IKEA-USA.com/warranty

Everyone deserves a refreshing bathroom

IKEA Bath faucets and accessories coordinate with everything you need for a great bath and shower experience: thermostatic faucets, head and hand showers with different spray functions and bathroom accessories, all in the same family. All IKEA showers are equipped with water and energy-efficient shower heads and hand showers. This is achieved by having a flow regulator, which reduces the water flow. You'll save up to 30% water and energy compared to a shower without a flow regulator. Everyone deserves a refreshing shower experience every day. What can be more revitalizing than knowing you can save water (and money on your water and energy bills) at the same time? Just pick and choose the shower function you need in your bathroom.

A high standard of accuracy has been sought in the preparation of this buying guide. We apologize for, but will not be bound by or responsible for, errors and omissions in this buying guide.

Not all products may be available in all stores. See what is available at your local store by visiting IKEA-USA.com. For more detailed product information, see the price tag or visit IKEA-USA.com. All products shown require assembly.



Bath Faucets

All bathroom faucets have a 10-year limited warranty. For details see [IKEA-USA.com/warranty](https://www.IKEA-USA.com/warranty)



SALJEN Sink faucet Plastic. Height 4¾".	
Black	204.003.23




PILKÅN Sink faucet Brass. Height 3⅞".	
Chrome-plated	205.328.61



ENSEN Sink faucet Brass. Height 4¾".	
Chrome-plated	305.325.49



DALSKÅR Sink faucet Brass. Height 7⅞".	
Stainless steel	505.325.34
Chrome-plated	905.325.27



LUNDSKÅR Sink faucet Brass. Height 9⅞".	
Black	105.327.29



BROGRUND Sink faucet Brass. Height 6¾".	
Chrome-plated	205.321.11



BROGRUND Sink faucet with sensor Brass. Height 5⅞".	
Chrome-plated	804.233.50




BROGRUND Sink faucet, tall Brass. Height 11".	
Chrome-plated	005.320.94




RUNSKÅR Sink faucet Brass. Height 3⅞".	
Brass	005.328.76
Chrome-plated	305.331.53



HAMNSKÅR Sink faucet Brass. Height 7½".	
Black	705.326.94
Chrome-plated	805.327.16




VOXNAN Sink faucet Brass. Height 7⅞".	
Chrome-plated	705.332.74




VOXNAN Sink faucet, tall Brass. Height 11¾".	
Chrome-plated	605.332.55

Shower Faucets


All thermostatic shower faucets include a free 10-year limited warranty and all the riser rails, head/hand showers and hoses include a free 3-year limited warranty. For details see IKEA-USA.com/warranty




BROGRUND Riser rail with hand shower and wall outlet
Hand shower Ø3½". Riser rail height 25½".
Chrome-plated finish 503.426.28



BROGRUND Bath/shower set with thermostatic faucet
Shower head Ø3½". Thermostatic faucet Ø7". Spout D6½".
Chrome-plated finish 903.426.26



VALLAMOSSE Riser rail with hand shower and wall outlet
Hand shower Ø3¾". Riser rail H24½".
Chrome-plated finish 703.519.33




VOXNAN Bath/shower set with thermostatic faucet
Shower head Ø3½". Thermostatic faucet Ø7". Spout D6½".
Chrome-plated finish 003.426.21



LILLREVET Single-spray hand shower
Hand shower Ø3¾".
White 503.426.33

ACCESSORIES



BOLLÖSUND Drawer organizer

Beige 805.708.88




BOLLÖSUND Drawer organizers

Beige 205.708.86 set of 4



BOLLÖSUND Toiletry bag

Beige 005.708.87



BROGRUND Towel rail L26½"

Stainless steel 303.285.34




BROGRUND Hanger for door W11½×H5½"

Stainless steel 203.285.44



BROGRUND Hooks

Stainless steel 205.246.77 2pk




BROGRUND Corner wall shelf unit W7½×D7½×H2¾"

Stainless steel 304.089.79



BROGRUND Glass shelf

W26¾×D4¾×H¾".
Tempered glass and stainless
steel 905.246.74



BROGRUND Toilet paper holder W5"

Stainless steel 003.285.40



BROFJÄRDEN Soap dish

Chrome-effect 505.815.48



BROFJÄRDEN Wall shelf/towel rail 29½×11¾"

Chrome-effect 205.822.38



BROFJÄRDEN Bath set

Gray 505.648.84 3pcs



BROFJÄRDEN Towel holder Ø8¼"

Chrome-effect 105.822.29




BROFJÄRDEN Towel rail L29¼"

Chrome-effect 505.822.32



BROFJÄRDEN Double hook

Chrome-effect 505.822.27



BROFJÄRDEN Shower shelf 13×4¾"

Chrome-effect 105.822.34



BROFJÄRDEN Toilet brush

Chrome-effect 105.815.50



BROFJÄRDEN Toilet paper holder

Chrome-effect 705.815.52



BROFJÄRDEN Trash can 1 gallon

Chrome-effect 205.821.82



VISSLAÄN Box with compartments, 12¾×12¼×3¼".
Small compartments practical for sorting items like hair
accessories and jewelry.

Brown-beige 005.621.04




VISSLAÄN Boxes with lids Includes: one box (8×8×3½"), one
box (8×4×3½") and three boxes (4×4×3½").

Brown-beige 905.545.38 set of 5



VISSLAÄN Drawer organizer, 13¾×4¼×1"

Brown-beige 405.621.16



VISSLAÄN Drawer organizers

Includes: one tray, (6½×3½×1"), one bottle holder
(6½×4¾×3½") and one toothbrush holder (2¾×3¾×4½").

Brown-beige 205.621.17 set of 3